


BLACK+ DECKER™

Tabletop Air Purifier

INSTRUCTION MANUAL

CATALOG NUMBER
BAPT01
BAPT02



Thank you for choosing BLACK+DECKER!

PLEASE READ BEFORE RETURNING THIS PRODUCT FOR ANY REASON.

If you have a question or experience a problem with your BLACK+DECKER purchase, go to www.blackanddecker.com/instantanswers

If you can't find the answer or do not have access to the Internet, call 844-299-0879 from 10:30 a.m. to 6:30 p.m. EST Mon. - Fri. to speak with an agent. Please have the catalog number available when you call.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

CONTENTS

SAFETY INFORMATION

Important Safety Instructions.....	3-4
Electrical Requirements.....	5

SET UP & USE

Parts & Features	6
Operating Instructions	7-10
Cleaning & Maintenance	11

TROUBLESHOOTING & WARRANTY

Troubleshooting.....	12
Limited Warranty.....	13-14

PRODUCT REGISTRATION

Thank you for purchasing our BLACK+DECKER product. This easy-to-use manual will guide you in getting the best use of your air purifier.

Remember to record the model and serial numbers. They are on a label in the rear.

Model number

Serial number

Date of purchase

Staple your receipt to your manual. You will need it to obtain warranty service.

SAFETY INFORMATION



DANGER

DANGER - Immediate hazards which **WILL** result in severe personal injury or death



WARNING

WARNING - Hazards or unsafe practices which **COULD** result in severe personal injury or death



CAUTION

CAUTION - Hazards or unsafe practices which **COULD** result in minor personal injury

IMPORTANT SAFETY INSTRUCTIONS



WARNING

When using electrical appliances, basic safety precautions should be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USE.
2. Only use the air purifier as described in this manual.
3. To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
4. Remove all packaging material, including the plastic wrap over the filter before use.
5. If the adapter, its cord, or plug is damaged, it must be replaced by the manufacturer. Do not attempt to use a substitute adapter as it could result in hazard and/or injury. Contact customer service for further assistance.
6. Check the household voltage to ensure it matches the appliance's rated specification.
7. Do not let cord touch any hot surface and make sure that it does not hang over a table edge or counter.
8. Place air purifier on a firm, flat, level surface.
9. Do not use this product on wet surfaces. This air purifier is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate air purifier where it may fall into bathtub or other water container.
10. Avoid exposure to direct sunlight.

SAFETY INFORMATION

11. Close supervision is necessary when any appliance is used by or near children.
12. To reduce the risk of electric shock, do not remove screws. Do not attempt to repair or replace parts except for filters.
13. Unplug the appliance before cleaning it. Wipe it with a soft cloth.
14. Unplug the air purifier before removing the filter.
15. Do not immerse the appliance or the power cord in water or other liquids.
16. Do not use any detergents, glass or household cleaner, furniture polish, gasoline, paint thinner or other solvent to clean any part of the air purifier.
17. If you spill any liquid on the unit, it can cause serious damage. Switch it off and unplug immediately.
18. Do not block, cover or obstruct the air vents. Do not place anything on top of the unit.
19. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
20. **WARNING** - To reduce the risk of fire or electric shock, DO NOT use this air purifier with any solid-state speed control devices.
21. Do not use outdoors.

**READ AND SAVE THESE
INSTRUCTIONS
HOUSEHOLD USE ONLY**

SAFETY INFORMATION

WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience or knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.


OPERATING CONDITION

The air purifier should be operated between a temperature range of 64°F (18°C) - 140°F (18°C) and a Relative Humidity under 90%.

NOTE: Unit performance may be affected when in use outside of these operating conditions.

SET UP & USE

PARTS & FEATURES



SET UP & USE


OPERATING INSTRUCTIONS

Before using the air purifier for the first time, remove all packaging material, including the plastic bag the filter is wrapped in.

NOTE: Refer to CLEANING AND MAINTENANCE section of this manual for information on how to access and install the filter.

Place the Air Purifier on a firm level surface with the controls facing upwards, making sure nothing is obstructing the air flow on any side of the air purifier.

Plug the AC power adapter into the AC input connection located at the bottom rear of the unit. Plug the AC adapter into the wall socket.


When the air purifier is plugged in, it will beep and the POWER  button will illuminate.




Tap the POWER  button on the air purifier to start the air purifier. The fan speed will set at LOW.


SET UP & USE


CONTROL PANEL

Model BAPT01



Press the SPEED  button repeatedly to scroll through LOW, MEDIUM, HIGH and SLEEP settings. When in sleep mode, the fan will operate at low speed. Only the  and the  lights will be illuminated

Press the LOCK  button for 3 seconds to turn on the child lock function. When the icon flashes the child lock is activated so that the settings cannot inadvertently be changed. Press the LOCK button again to turn the child lock off. When the icons are illuminated, the child lock function is not activated.

Press the TIMER  button to scroll through the number of hours (1H, 2H, 4H, 8H) and select the number of hours for the air purifier to shut off.

 REPLACE FILTER Indicator Light

After 2,000 hours of use, the REPLACE FILTER indicator light will flash and there will be an audible beep. Replace the filter with a new one. Press the REPLACE FILTER indicator light for 3 seconds until the control panel lights illuminate and the unit will no longer make a beeping sound


NOTE: Refer to CLEANING AND MAINTENANCE section of this manual for information on how to access and install the filter.




To shut off the unit at any time, press the POWER  button until all indicator lights to OFF.


SET UP & USE


CONTROL PANEL

Model BAPT02



Press the SPEED  button repeatedly to scroll through LOW, HIGH, AUTO and SLEEP settings. In AUTO mode, the fan speed is automatically set according to the air quality in the room. When in sleep mode, the fan will operate at a lower speed. Only the  and the  lights will be illuminated

Press the LOCK  button for 3 seconds to turn on the child lock function. When the icon flashes the child lock is activated so that the settings cannot inadvertently be changed. Press the LOCK button again to turn the child lock off. When the icons are illuminated, the child lock function is not activated.

Press the TIMER  button to scroll through the number of hours (1H, 2H, 4H, 8H) and select the number of hours for the air purifier to shut off.

 REPLACE FILTER Indicator Light

After 2,000 hours of use, the REPLACE FILTER indicator light will flash and there will be an audible beep. Replace the filter with a new one. Press the REPLACE FILTER indicator light for 3 seconds until the control panel lights illuminate and the unit will no longer make a beeping sound

NOTE: Refer to CLEANING AND MAINTENANCE section of this manual for information on how to access and install the filter.

To shut off the unit at any time, press the POWER  button until all indicator lights to OFF.

SET UP & USE

AIR QUALITY INDICATOR LIGHTS

model BAPT02 only


This model has indicator lights which will change color according to the air quality detected by the particle sensor.

Color of light	Air Quality
Blue	Excellent
Green	Good
Purple	Fair
Red	Poor

The air quality indicator lights will not glow when the air purifier is in sleep mode.

OPTIONAL AROMATHERAPY

Your air purifier comes with 2 sponges located on the bottom filter cover that allows you to add essential oils (not included). If you wish to add fragrance to the air, moisten the sponges and add a drop of the essential oil fragrance of your choice on to each sponge. The fan will disperse the fragrance in the air through the air vents.



SET UP & USE

CLEANING AND MAINTENANCE

⚠ WARNING: Be sure to unplug from the electrical supply source before cleaning or changing the filter.

Do not use liquids to clean the air purifier.


Do not attempt to disassemble the air purifier for cleaning.


- Wipe the exterior of the air purifier with a soft, dry cloth. Make sure the particle sensor does not become clogged with dust.
- If necessary, wipe only the exterior housing with a damp cloth, then immediately dry.
- You can vacuum the inside of the air purifier.

FILTER INSTALLATION

Your air purifier comes with a 3-stage (Pre-filter + HEPA+ Activated Carbon) Filter. To access the filter, turn the bottom filter cover by the handle counterclockwise (towards the unlock symbol) to remove it. Lift the filter out of the air purifier. Remove the plastic bag and reinstall the filter.

Replace the filter cover by turning it clockwise (towards the lock symbol) until it locks in place.



The REPLACE FILTER  indicator light will illuminate after 2,000 hours of use. You may need to replace the filter sooner if you are using the air purifier in an environment with poor air quality. If you notice that the filter does not appear visibly clean, or air purification seems to have decreased, the filter should be replaced.

REPLACEMENT FILTER

Use Replacement Filter Model AF1. To purchase a replacement filter, it is recommended that you check with the retailer where you purchased your air purifier, or major online retailers. You can also contact the BLACK+DECKER Customer Satisfaction Center at 844-299-0879 or service@equitybrands.com.

NOTE: After replacing the filter, press the REPLACE FILTER indicator light for 3 seconds until the control panel lights illuminate and the unit does not make any beeping sound in order to reset it.


STORAGE

If you are not going to use the air purifier for a long time make sure it is clean and dry. Wrap the filter in plastic. Store in a cool dry place.

TROUBLESHOOTING & WARRANTY

Troubleshoot your problem by using the chart below. If the air purifier still does not work properly, contact the BLACK+DECKER customer service center or the nearest authorized service center.

⚠ WARNING: Users must never troubleshoot internal components.

TROUBLE	POSSIBLE CAUSE	POSSIBLE REMEDY
Appliance does not turn on	Appliance is not plugged in	Check that the AC Power Adapter is properly connected to the air purifier and that the adapter is plugged into a working outlet
The fan does not work	Something is obstructing the fan. Packing material may not have been removed	Make sure nothing is obstructing the fan and all material has been removed from the unit and the filter.
The air purifier beeps	The filter needs to be replaced	Replace filter
	The filter was not installed correctly	Make sure the filter was installed properly with the plastic bag removed. After installing the filter, press the REPLACE FILTER indicator light for 3 seconds
The air purification is poor	There is not enough clearance around the air purifier	Make sure nothing is obstructing the airflow around the air purifier.
	Air Purifier is set at a low speed setting	Set at a higher speed setting
	The filter needs to be replaced	Replace filter
Air purifier is noisy	Something may be obstructing the fan or an object may be inside the air purifier	Remove any foreign object from the air purifier
	The plastic packaging may not have been removed from the filter.	Make sure the filter was installed on a firm level surface with the plastic bag removed
The REPLACE FILTER  light is still illuminated after replacing the filter	The filter was not installed correctly or the filter was not reset by pressing the REPLACE FILTER button	Make sure the filter was installed properly with the plastic bag removed. After installing the filter, press the REPLACE FILTER indicator light for 3 seconds
Air quality indicator is always red (Model BAPTO2 only)	There is a source of pollution near the air purifier such as someone is smoking.	After operating the air purifier for a period of time, the air quality indicator will turn blue or green when the air quality is getting better.
	The particle sensor may be clogged with dust or other debris.	Wipe the particle sensor and make sure there is no dust or debris obstructing it.

SPECIFICATIONS

- Voltage: DC 24V
- Unit Dimensions (W x D x H): 8.9" x 8.9" x 12.2"
- Net Weight: Approx. 3.3 lbs

TROUBLESHOOTING & WARRANTY

BEFORE YOU CALL FOR SERVICE

IF THE APPLIANCE FAILS TO OPERATE:

- A) Check to make sure that the air purifier is plugged in securely. If it is not, remove the plug from the outlet, wait 10 seconds and plug it in again securely.
- B) Check for a blown circuit fuse or a tripped main circuit breaker. If these seem to be operating properly, test the outlet with another appliance.

IF NONE OF THE ABOVE SOLVES THE PROBLEM, CONTACT A QUALIFIED TECHNICIAN.

⚠ WARNING: USER SHOULD NOT TRY TO ADJUST OR REPAIR THIS APPLIANCE. THERE ARE NO USER SERVICEABLE PARTS INSIDE.

IMPORTANT

DO NOT RETURN THIS PRODUCT TO THE STORE

If you have a problem with this product, please contact the BLACK+DECKER Customer Satisfaction Center at 844-299-0879 or service@equitybrands.com

DATED PROOF OF PURCHASE, MODEL # AND SERIAL #
REQUIRED FOR WARRANTY SERVICE

TROUBLESHOOTING & WARRANTY

LIMITED WARRANTY

Any repair, replacement, or warranty service, and all questions about this product should be directed to **BLACK+DECKER** at **844-299-0879** from the USA or Puerto Rico.

BLACK+DECKER warrants to the original purchaser that the product will be free from defects in material, parts and workmanship for the period designated for this product. The warranty commences the day the product is purchased and covers up to a period of **1 year (12 months) for labor/1 year (12 months) for parts (manufacturing defects only)**.

BLACK+DECKER agrees that it will, at its option, replace the defective product with either a new or remanufactured unit equivalent to your original purchase during the warranty period.

Exclusions: This warranty does not apply to the below:

1. If the appearance or exterior of the product has been damaged or defaced, altered or modified in design or construction.
2. If the product original serial number has been altered or removed or cannot be readily determined.
3. If there is damage due to power line surge, user damage to the AC power cord or connection to improper voltage source.
4. If damage is due to general misuse, accidents or acts of God.
5. If repair attempts are done by unauthorized service agents, use of parts other than genuine parts or parts obtained from persons other than authorized service companies.
6. On units that have been transferred from the original owner.
7. On products that have been purchased as refurbished, like new, second-hand, or an "As-Is" or "Final Sale" terms.
8. To products used in a commercial or rental setting.
9. To products used in settings other than ordinary household use or used other than in accordance with the provided instructions.
10. To damages for service calls for improper installations.
11. Transportation and shipping costs associated with the replacement of the unit.
12. Service calls to instruct you how to use your product.
13. Service calls to repair or replace the house fuse, reset the circuit breaker or correct the wiring in the house.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER; **BLACK+DECKER** SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THE WARRANTY.

Some states do not allow the exclusion or limitations of incidental or consequential damages, or limitations on how long the warranty lasts. In these cases the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Obtaining Service: To obtain service, product literature, supplies or accessories please call **844-299-0879** to create a ticket for exchange/repair. Please make sure to provide the date of purchase, model number and a brief description of the problem. Our customer service representative will contact you or send detailed return instructions.

BLACK+DECKER does not warrant that the appliance will work properly in all environmental conditions, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose other than the purpose identified within this user's manual. **BLACK+DECKER** has made every effort ensure that this user's manual is accurate and disclaims liability for any inaccuracies or omissions that may have occurred. Information in this user's manual is subject to change without notice and does not represent a commitment on the part of **BLACK+DECKER**. **BLACK+DECKER** reserves the right to make improvements to this user's manual and/or to the products described in this user's manual at any time without notice. If you find information in this manual that is incorrect, misleading, or incomplete, please contact us at **844-299-0879**.

W Appliance Co.
1356 Broadway
New York, NY 10018

BLACK & DECKER, BLACK+DECKER, the BLACK & DECKER and BLACK+DECKER logos and product names and the orange and black color scheme are trademarks of The Black & Decker Corporation, used under license. All rights reserved.

Product in this box may differ slightly from that pictured. Does not affect function. Not all accessories shown in photography are included in this package.

Imported by W Appliance, Inc., 1356 Broadway, New York, NY 10018