




## SPIRIAL SLICER & GRATER (With suction base)-CH1513

### Safety instructions

#### **WARNING**

- Please clean before use
- Attention! The blades are very sharp! Carefully place and remove!
- Keep the product out of reach of children!
- The product is designed for household use, not for commercial use.

### Assembly and use



#### **SLICER**

- Use suction base for stability.
- Put the food into the food holder carefully.
- Rotate handle to slice and Switch for strands or slices.
- Clear bowl for collection

#### **GRATER**

- Cover multifunctional base on clear bowl
- Change the knife you on carefully
- Use safe holder to grater

### Cleaning and care

#### **WARNING**

- Clean with tap water and detergent.
- Hand wash recommended