


5 YEAR WARRANTY





USER MANUAL MODEL: PEHNDFN-W

### WARNINGS AND PRECAUTIONS



- When connecting the USB cable for charging, be sure to insert the USB plug into the charging port correctly to charge the battery and avoid damage to the product.
- DO NOT put the fan in a high-temperature place or overexpose it to the sun.
- DO NOT put the fan in a wet or humid place.
- DO NOT put the fan on an unstable surface.
- DO NOT attempt to disassemble the fan.
- DO NOT let children operate the product alone.
- When you are not using the fan, please make sure it is turned off to avoid unexpected accidents caused by extended run times.
- DO NOT put sharp objects into the fan blade area when the product is turned on.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on PureBreeze™. Doing so will void the warranty. The inside of this unit contains no user serviceable parts.
- DO NOT use a USB adapter with greater than 5V/2.1A to charge this product.

# FCC NOTICE

Model: PureBreeze<sup>™</sup> Rechargeable Handheld Fan (PEHNDFN-W) This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

> Pure Enrichment 2803 S Yale St. Santa Ana, CA 92704 pureenrichment.com

The product is protected against unauthorized use. DO NOT modify it without the authorization of the manufacturer, or the user's authority to operate could be voided.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# PRODUCT SPECIFICATIONS


Size:	3.5" L x 1.6" W x 7.5" H
Power:	DC 5V, 5W
Fan Speed:	3 Speeds: Low, Medium, High
Run Time:	4 Hrs (Low), 2.2 Hrs (Medium), 1.3 Hrs (High)
Noise Level:	40dBA (Low) to 53dBA (High)
Battery:	Lithium Ion Rechargeable Battery 18650 - 3.7V

### INTRODUCTION

Thank you for purchasing the PureBreeze™ Rechargeable Handheld Fan from Pure Enrichment. This portable 3-speed fan is designed to generate powerful airflow in your personal space to keep you cool wherever you go.

## **PRODUCT FEATURES**

The diagram below highlights all of the important features of the unit.



## REPLACEMENT SCENT PADS

Replacement scent pads are available at www.pureenrichment.com. Use Model No: PEHNDFN-W to select the correct pads for this unit.

# **OPERATING INSTRUCTIONS**

#### USING THE FAN

Press the Control Button to turn on the fan. 1st touch: Turn on, Low speed 2nd touch: Medium speed 3rd touch: High speed 4th touch: Turn off



### CHARGING THE FAN

The battery should be recharged when the white LED indicator light around the control button blinks.

- 1. Connect the fan to a power supply with the included USB cable.
- When charging, the orange indicator light will be on. When the light turns off the fan is fully charged.

\*Please note that the fan can only run on low speed while charging.

### NOTE:

- Input power voltage must be DC 5V.
- Input current must be at least 1A.
- This unit is NOT compatible with USB PD/SCP/SoC quick chargers.

# USING THE SCENT PADS



1. Remove the cover



3. Add 3-4 drops of essential oil



2. Insert the scent pad



4. Replace the cover

# WARRANTY

PureBreeze™ comes with an industry-leading 5 Year Warranty that begins on the date of purchase.

The warranty applies to the fan and necessary parts and labor relating thereto. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

## PRODUCT REGISTRATION

To ensure your full warranty, and to receive product updates and streamlined customer support, remember to register your product at:

www.pureenrichment.com/productregistration

# ARE YOU 100% SATISFIED?

If you have product questions or concerns, don't hesitate to contact us directly:

Email: help@pureenrichment.com Phone: (657) 275-3737

(Available Monday-Friday, 8am-5pm PST)

Pure Enrichment has an award-winning warranty, exchange, and customer service program that guarantees hassle-free solutions within 24 hours to any issue you might have!



Santa Ana, CA 92704 pureenrichment.com