



PURERELIEF EXPRESS

DESIGNER SERIES HEATING PAD



USER MANUAL MODEL: PEHPNVGR

IMPORTANT SAFETY INSTRUCTIONS DO NOT DESTROY

DANGER: TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK, FIRE, AND PERSONAL INJURY, THIS PRODUCT MUST BE USED IN ACCORDANCE WITH THE FOLLOWING INSTRUCTIONS:

- 1. READ ALL INSTRUCTIONS.
- 2. DO NOT USE WHILE SLEEPING.
- DO NOT USE ON AN INFANT.
- 4. THIS PAD IS NOT TO BE USED ON OR BY AN INVALID, SLEEPING OR UNCONSCIOUS PERSON, OR A PERSON WITH POOR BLOOD CIRCULATION UNLESS CAREFULLY ATTENDED.
- 5. DO NOT USE ON AREAS OF INSENSITIVE SKIN.
- 6. BURNS CAN OCCUR REGARDLESS OF CONTROL SETTING. CHECK SKIN UNDER PRODUCT FREQUENTLY.
- 7. NEVER USE PAD WITHOUT COVER IN PLACE.
- DO NOT USE PINS OR OTHER METALLIC MEANS TO FASTEN THIS PAD INTO PLACE.
- DO NOT SIT ON OR CRUSH PAD AVOID SHARP FOLDS.

- 10. NEVER PULL THIS PAD BY THE SUPPLY CORD.
- 11. DO NOT USE THE CORD AS A HANDLE.
- 12. CAREFULLY EXAMINE INNER COVER BEFORE EACH USE. DISCARD THE PAD IF INNER COVERING SHOWS ANY SIGN OF DETERIORATION.
- 13. LOOP CORD LOOSELY WHEN STORING, TIGHT WRAPPING MAY DAMAGE CORD AND INTERNAL PARTS.
- 14. THIS HEATING PAD HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE. THIS PLUG WILL FIT INTO A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN TO INSTALL THE PROPER OUTLET. DO NOT ATTEMPT TO DEFEAT THIS SAFETY FEATURE.

3

15. SAVE THESE INSTRUCTIONS.

INTRODUCTION

Thank you for purchasing the PureRelief Express Designer Series Heating Pad from Pure Enrichment. We created a vibrant fabric cover for this non-vinyl heating pad to add a touch of style to your temporary heat therapy. Use it as needed to relax the muscles in your back, legs, arms, and more.

USING PURERELIEF EXPRESS

To turn PureRelief Express on, press the power button. Select the desired heat setting by continuing to press the power button until the heat indicator light is the color of your desired heat setting:

Green=Warm Orange=Medium Yellow=Low Red=High

To turn PureRelief Express off, scroll through all the heat settings until the heat indicator light turns off.

NOTE: The "high" indicator light will blink red when an error occurs. If this happens, unplug PureRelief Express from the electrical outlet. Check the physical condition of the cord and the wall outlet.

If the blinking persists after you confirm a proper connection, contact Pure Enrichment at: help@pureenrichment.com

AUTO-OFF FEATURE

To conserve energy and prevent skin burns caused by excessive use, PureRelief Express includes an auto-off feature. The unit will turn off automatically after two hours of continuous use. The red auto-off light will blink when this feature is activated.

NOTE: After a power outage, PureRelief Express automatically resets the timer on the auto-off feature.

WASHING INSTRUCTIONS

To maintain the quality of the fabric cover, proper care and cleaning is essential. Follow these washing instructions:

- 1. Unplug the heating pad from the electrical outlet.
- 2. Remove the fabric cover from the heating pad.
- Machine wash only the fabric cover in cold water on the gentle cycle or hand wash with mild detergent.
- 4. Hang drying is recommended.
- Do not wash the heating pad. Wipe clean with a damp cloth as needed. Do not dampen the cord or heat controller
- Make sure the fabric cover is completely dry before placing it back on the heating pad.

PRODUCT SPECIFICATIONS

Pad Size:	12" x 24"
Power Supply:	AC: 120V, 60Hz, 70W
Pad Cover Material:	Polyester
Auto Shut-Off Timer:	120 minutes
4 Heat Settings:	Warm-temperature range (~110° F) Low-temperature range (~120° F) Medium-temperature range (~130° F) High-temperature range (~140° F)

WARRANTY

PureRelief Express comes with an industry-leading 5 Year Warranty that begins on the date of purchase.

The warranty applies to the heating pad and necessary parts and labor relating thereto. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

PRODUCT REGISTRATION

To ensure your full warranty and to receive product updates and streamlined customer support, remember to register your product at:

www.pureenrichment.com/productregistration

ARE YOU 100% SATISFIED?

If you have product questions or concerns don't hesitate to contact us directly at:

help@pureenrichment.com

Pure Enrichment has an award-winning warranty, exchange, and customer service program that guarantees hassle-free solutions to any issue you might have within 24 hours!

FCC NOTICE

Model: PureRelief Express Designer Series Heating Pad (PEHPNVGR)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pure Enrichment 14505 Astronautics Ln Huntington Beach, CA 92647 www.pureenrichment.com

The product is protected against unauthorized use. DO NOT modify it without the authorization of the manufacturer, or the user's authority to operate could be voided.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Huntington Beach, CA 92647 www.pureenrichment.com