



bentgo<sup>®</sup>  
glass

Oven-Safe Glass Storage with Easy-Snap Lid

- 1 Large Compartment for Main Snack
- 1 Small Compartment for Sides or Dips



bentgo<sup>®</sup>  
glass

**For Best Results:**

- Before use, wash by hand or dishwasher (top rack only).
- Silicone seal can be removed for cleaning. Hand wash and let dry completely before returning to lid.
- After washing and once the lid is dry, push the silicone seal fully into the lid with the grooves in the seal facing up. If the seal is not fully seated in the lid, you may have difficulty snapping the tabs shut and leakage can occur.
- Avoid abrasive cleaners or scrub pads while cleaning to prevent scratching.
- Glass can be used in the oven, microwave, dishwasher, and freezer.
- Do NOT heat an empty container in the oven or microwave.
- Do NOT use container on the stove top, grill, or over a campfire.
- Do NOT use lids in the oven.
- For best performance, secure all tabs before moving, refrigerating, or freezing your filled Bentgo Glass container.

Total Volume 1.75 Cups | 14oz | 414mL

Oven-Safe Glass Storage with Easy-Snap Lid  
1 Large Compartment for Main Snack  
1 Small Compartment for Sides or Dips

bentgo<sup>®</sup>  
glass

