

# SIZING GUIDE

## COLLAR

	<b>13" - 16"</b>		<b>15" - 18"</b>
<b>1.2" Wide</b>	<b>SMALL</b>	<b>1.5" Wide</b>	<b>MEDIUM</b>
	<b>17" - 22"</b>		<b>20" - 28"</b>
<b>1.5" Wide</b>	<b>LARGE</b>	<b>2" Wide</b>	<b>X-LARGE</b>



**MEASURE**  
Measure your dog's neck first, as dogs come in all different shapes & sizes. Leave space for two fingers between collar & dog.

**INSTRUCTIONS:** Gently press together both ends of Boss Tactical™ collar, until securely locked. Use two fingers to gently press both "triggers" simultaneously to unlock.

**CAUTION:** Not for tie out. Prior to putting on the collar, adjust accordingly (see sizing image). Sizing should allow room for two fingers between the dog and the collar.

## LEASH

**INSTRUCTIONS:** Once collar is securely on the dog, gently press together the D-ring from the Boss Tactical™ collar with the 'open-end' of the Boss Tactical™ leash clip until securely locked. Use two fingers to gently press both "triggers" simultaneously to unlock clip.


	<b>4' Leash</b>		<b>6' Leash</b>
<b>1.25" Wide</b>	<b>4 FT</b>	<b>1" Wide</b>	<b>6 FT</b>

**CAUTION:** Not for tie out. Temporary tie-out option intended to be used for a short duration under close supervision.

## HARNESS

**INSTRUCTIONS:** Adjust each of the straps accordingly to best fit your pet. Unbuckle Boss Tactical™ clips, by pressing both triggers simultaneously, and gently slipping the harness over your dog's head and legs. Make sure that the (two) D-rings are on the top for proper fitting. Buckle all of the Boss Tactical™ clips securely, and adjust the straps until you can gently slip two fingers underneath any of the straps. Try to pull the harness over your dog's head to make sure that the harness is secure.

<p><b>SMALL</b> Chest - 20"-31" Neck - 14"-21"</p> <p><b>MEDIUM</b> Chest - 22"-33" Neck - 16"-22"</p>	<p><b>LARGE</b> Chest - 24"-37" Neck - 18"-29"</p> <p><b>X-LARGE</b> Chest - 26"-42" Neck - 20"-31"</p>
--	---



**CAUTION:** Not for tie out. Prior to putting on the harness, adjust accordingly (see instructions). A proper fit should allow modest room for two fingers to slip between the dog and the harness.