

protect. teach. love.

3 in 1 Harness

How To Measure

Chest Girth – Wrap measuring tape around the deepest part of the dog's rib cage behind

1

- the front legs

 Neck Girth Wrap measuring tape around the widest part of
- tape around the widest part of the dog's neck

Harness Size	Weight Range	Girth Measurement	Neck Girth Measurement

X-Small 10-20 lbs. 13"-19" Girth 9"-14" Neck Small 20-35 lbs. 19"-24" Girth 14"-18" Neck

Medium 35-65 lbs. 24"-34" Girth 18"-26" Neck Large 65-95 lbs. 29.5"-42.5" Girth 24"-38" Neck