




NOTICE Please retain these instructions for future reference.

- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be aware that moving parts can injure, crush and cut.
- If any parts are missing,broken,damaged,or worn,stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer' s instructions as this could void the product warranty.












PRODUCT ASSEMBLY

Screw the curtain Part A to the INSIDE of Part B by 2xP4. Screw Part C to the INSIDE of Part B by 2xP1.




Screw the curtain Part A to the INSIDE of Part D by 2xP4. Screw Part C to the INSIDE of Part D by 2xP1.






PRODUCT ASSEMBLY





Slide in the two layer panels.



PRODUCT ASSEMBLY





Attach 4pcs of P4 to the feet of the cat house.





WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate miantenance, or neglect of this product.