## HALLOWEEN FIGURINE ASSEMBLY INSTRUCTIONS

The model number of your item is printed on the side of your carton. Always use this number to identify your item.

Thank you for your purchase of this quality Halloween decor. With proper use and care, your Halloween decor will provide you with years of enjoyment. Please follow the instructions on how to assemble and disassemble your item. If you should have any problems with your item, or you have any questions, DO NOT return it to the place of purchase. Please call our toll-free number: **1-888-840-4559** and a customer service representative will assist you. Enjoy your Holiday!


# **IMPORTANT SAFETY INSTRUCTIONS**


# 

- 1. This product is for indoor or covered outdoor use only. Do not place in direct sunlight.
- 2. This product is for decoration only and is not a toy. Please use caution with children under the age of 8.
- 3. Do not position the decoration near candles, sources of heat, or in direct sunlight.
- 4. The decoration cannot be connected to the power supply directly.
- 5. Decoration should be on a level, stable surface to prevent it from falling over.
- 6. This product is fragile and should be assembled with care.
- 7. Please follow the steps and requirements specified in the instruction to ensure safety and reliability during the installation.

**Storage tips:** We suggest saving the carton for storing your decor. Store in a cool, dry area where the temperature does not exceed 100°F.

#### A SCREWDRIVER IS NEEDED FOR ASSEMBLY SCREWDRIVER NOT INCLUDED





## STEP 1:

Use a screwdriver to unscrew the 2 screws that are fixed to the back holding the ground stake.

Turn the stake to correct position and reattached with 2 screws. (See figure 1 & 2)

## STEP 2:

Place the cauldron back side up on a clean surface and place the legs in the position shown below. Use a screwdriver to attach legs as shown. (See figure 3)

Take care to make sure screws do not break through front of the cauldron.