

Instruction Manual Please save this manual for future reference.

Product Name:	4Ft Pre-Lit LED Battery-Operated with Timer Artificial Flocked Fir Christmas Tree with Square Planter
Product #:	WHAP1657

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

CARTON CONTENTS:

Every carton will contain a top section and a bottom section, and base container.

Before You Start

- Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully.
- Retain the instructions for future use and save the carton for storing your tree.

Assembly and Instruction Procedure (no tools required for assembly):

- Remove the tree and base from its packaging. Be sure to remove all contents.
- Choose a location where the tree is to be displayed.
- Put the pot base on the floor then insert the tree body into the pot firmly.
- Gently fan the branch tips of the artificial tree down towards the container. Take care not to place unnecessary pressure
 on the brackets during assembly.
- The branches on your tree can be adjusted and fluffed to give your tree the desired fullness. For best results, straighten and separate all branch tips, then bend them slightly upward.
- Place 3 AA disposable batteries (not included) to the battery box. Please be sure to load the batteries correctly.

Settings:

- On/Off switch to manually turn the lights off and on.
- Set to "Timer" and the lights will automatically turn on for 6 hours, and shut off for 18 hours.

Warnings:

- MARNING Risk of Fire and Electric Shock.
- Read all instructions and warning tags included with this tree.
- Do not place near fireplaces, candles, outdoor heaters, or other similar sources of heat.
- Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
- After fully assembly, add the batteries to the battery box.
- Keep wires clear of being pinched or cut during assembly or installation. Discard sets with cut or pinched insulation.
- Do not press or grasp bulbs during assembly or installation.
- Make sure final assembly stable enough to hold the tree upright.
- Do not use candles on tree. Use only with the included mini lights.
- This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.



Instruction Manual

Please save this manual for future reference.

Product Name:	4Ft Pre-Lit LED Battery-Operated with Timer Artificial Flocked Fir Christmas Tree with Square Planter
Product #:	WHAP1657

Storage Tips:

- Warning Remove batteries from the battery box.
- Remove all decorations.
- Remove tree from container by pulling up on center pole at base of tree.
- Starting from the top, carefully press the tips back up against the stem.
- Store the product in a cool, dry location away from sunlight where the temperature does not exceed 35°C (95°F).

MADE IN CHINA