



T-Boss 550, 550F, and 550X LUBRICATION GUIDE

Guide for checking Differential and Engine Oils





The Rear Differential drain plug is located here.





Using a 17mm 6-sided socket (do not use 12-sided socket) loosen the Drain Plug.

Unscrew by hand to remove.





Check the oil level by placing your finger inside the drain plug.

If you cannot feel oil, you will need to add.

REAR DIFFERENTIAL ADDING OIL



Fill oil until you reach the bottom thread.

Always use 80W 90 GL5 oil.

Replace Drain Plug. Do not exceed 19 ft.lb. of torque.






LOCATING THE DRAIN PLUG - CLOSE UP



You will need an 18" extension with 17mm 6-sided socket. Remove Drain Plug.

Fill the oil to the bottom of the thread.

Always use 80W 90 GL5 oil.









The Fill Port will hold 2.3 qts. of oil. Use the levels on the Dip Stick to determine how much oil to add.

Always use 10W 40 Synthetic Blend designed for use with wet clutch.





www.MassimoMotor.com