

G2453A

03/2023

() IMPORTANT ()

Select your preferred configuration before beginning assembly; individual, long, wide.

Review all steps and understand assembly before beginning.

Do not fully tighten hardware until all components have been loosely assembled.

ASSEMBLY -- INDIVIDUAL

NOTE: Placement of Bolt Sets G, as noted during individual assembly, is recommended but not required. If you decide to join the planter boxes into the long or wide configuration, it will be easier to identify the bolts required for connecting two separate units.





G2453A

Page 3 / 5



Care & Maintenance

HELPFUL HINT: Lining the planter box with landscaping fabric is recommended. Lining the planter box can help prevent soil from escaping through the bottom, help retain soil moisture, insulate the soil against extreme temperatures, and could help maintain the overall appearance of the garden bed.

LEVEL SURFACE: Select a flat, level surface to place the raised planter boxes before filling and using it.

INSPECT: Periodically check all nuts and bolts and tighten as necessary.

MOVING: Only move the unit(s) when the planter box is empty; remove soil if necessary. Do not drag the garden bed as doing so may weaken assembly points and could cause breakage.

CLEANING: Wipe surfaces with a soft cloth.

For stubborn dirt, use a mixture of soap and water and wash with a soft cloth. Rinse all soap residue with a garden hose. Dry with a soft cloth to prevent rust on hardware and at assembly points.

STORAGE: Maintain the appearance and prevent damage by emptying and storing indoors when not in use.

SCRATCHES: The powder coating is tough and durable, but some scratching is inevitable. To prevent rust, wipe scratched areas to remove moisture. Scratches can be repaired with rust-resistant paint (not included); consult an expert at your local hardware store.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR TOUCH-UP PAINT.

👠 SAFETY STATEMENTS & WARNINGS 🕂

- Do not exceed the weight capacity of the planter box or shelf.
- Do not sit, stand, or climb on any part of the unit(s).
- Inspect hardware often and tighten loose hardware as needed.
- Keep the unit a safe distance away from heat sources such as fire pits, patio heaters, and grills.
- Do not use harsh chemicals or abrasive materials to clean this unit.

Any modification to the product or failure to follow recommended care will void the product warranty.

AWARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Sunnydaze Decor

G2453A

SunnydazeDecor.com

• • (