

|--|


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <a href="https://tiny.cc/SunnydazeWarranty">https://tiny.cc/SunnydazeWarranty</a> If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email:


customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

# **BOOKSHELF WITH STAGGERED SHELVES**RTA-058

Carefully review assembly and care instructions before using this product. Save this document for future reference.

Assemble components on a soft, clean surface to avoid scratching or damaging the finish.





No.	Parts		QTY.
Α		Bottom Panel	1
В	··	Large Shelf	1
С	[:::::.	Left Panel	1
D	: : : : :	Right Panel	1
Е	• .	Left Shelf	3
F		Right Shelf	3
G	1, 1, 1, 1	Top Back Panel	1
Н		Bottom Back Panel	1
I		Toe Board	2
J		Top Panel	1
K		Divider Panel	1

No.		HARDWARE	Q.	TY.
1		Wood Dowel	4	10
2	•••	Spreading Bolt	2	20
3		Cam Lock	2	20
4	<b>)</b>	Tack Glide	(	6
5		Cover Cap	2	20
6	<u></u>	Corner Brace	:	2
7	@m>	M6 x 9/16" Screw	:	2
8	@uun>	5/32" x 1" Screw		2
9	0 <u></u>	Wall Anchor		2

Tools Required (not included)			
	Phillips Screwdriver		
	Rubber Mallet		
	Power Drill with 1/4" Drill Bit		



Sunnydaze Decor

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

# INTRODUCTION

# Read the manual carefully to ensure you fully understand all use, care, assembly, and safety information.



Read this manual carefully and follow the assembly instructions in the order listed. Pay close attention to assembly drawings.



Regularly clean with a clean microfiber cloth to prevent dust accumulation.



Assemble on a soft, flat, clean, and drv surface.

Use a soft, protective barrier when assembling the furniture.

TIP: Use the box carton as a protective layer to separate and protect the parts from scratches and other damage during assembly.



Do not paint the unit.

Do not use abrasive materials or cleaners to clean the furniture: only use a slightly moistened cloth.



Indoor use only.

Do not expose the furniture to heat or humidity.



Do not push or drag furniture as doing so may damage the unit.

Only move furniture when it is empty.



Always ask for help when moving furniture.



When cleaning nearby furniture, do not allow contact with water or cleaners as they can deteriorate the furniture.



Do not allow metal components to come in contact with water or cleaners as it may cause rust and staining.



Avoid Accidents - Do not climb, sit or stand on the furniture.

Do not allow children to play on or inside the furniture.




Keep sharp objects away as they may scratch or damage the unit.

Do not use the furniture as a writing surface without a padded barrier.

## ↑ IMPORTANT INSTALLATION INFORMATION

For the stability of the unit, it is important that furniture connectors are installed correctly. See drawings and tips below for proper installation.

### **Wood Dowel**




Install wood dowels by gently tapping them into the designated hole using a rubber mallet.

# **Spreading Bolt**



Install Spreading Bolts by firmly pressing them into the hole or gently tapping with a rubber mallet until the shoulder is flush with the panel.

## Cam Lock





Align the cam lock opening (arrow) with the pre-drilled hole on the side of the panel. Use a screwdriver to adjust alignment as needed.




# **ASSEMBLY**

# Review all steps carefully and understand assembly before beginning.







STEP 3


TOOLS REQUIRED

Install one Wood Dowel (1), five Spreading Bolts (2), one Cam Lock (3), and two Tack Glides (4) into Left Panel (C) as shown.


Install one Wood Dowel (1), five Spreading Bolts (2), one Cam Lock (3), and two Tack Glides (4) into Right Panel (D) as shown.


Install two Wood Dowels (1) into Bottom Panel (A) as shown.
Turn the panel over.
















Install two Cam Locks (3) into Bottom Panel (A) as shown.

Install two Wood Dowels (1), and one Spreading Bolt (2) into Large Shelf (B) as shown.

Turn the panel over.


Install two Cam Locks (3) into Large Shelf (B) as shown.





**3**: 2

Tools Required



Tools Required


STEP 9

**E**: 3


Install two Cam Locks (3) into Top Back Panel (G) as shown.


Install two Wood Dowels (1) and two Cam Locks (3) into Left Shelf (E) as shown.


Repeat this step for the two remaining Left Shelves (E).














1


Install two Wood Dowels (1) and two Cam Locks (3) into Right Shelf (F) as shown.


Repeat this step for the two remaining Right Shelves (F).


Install three Spreading Bolts (2) into Top Panel (J) as shown.

Install six Wood Dowels (1) and one Tack Glide (4) into Toe Board (I) as shown.

Repeat this step with the remaining Toe Board (I).









Install four Wood Dowels (1) into Bottom Back Panel (H) as shown.

**STEP 16** 




Place Divider Panel (K) and Bottom Back Panel (H) onto Bottom Panel (A) as shown.

#### **STEP 14** Tools Required **K**: 1 1: 4



Install four Wood Dowels (1) into Divider Panel (K) as shown.


**STEP 17** 



With the spreading bolt facing upward, place Large Shelf (B) onto Divider Panel (K) and Bottom Back Panel (H).


#### **STEP 15**

NOTE: Components assembled during steps 15-17 are loosely fixed.



Align Bottom Panel (A) with the dowels in two Toe Boards (I) as


# shown.




Align three Shelves (E) with the left side of Top Back Panel (G).

Use a screwdriver to turn the cam lock until it locks onto the head of the spreading bolt.


Repeat to secure three Right Shelves (F) to the right side of Top Back Panel (G).




Align the bottom of Top Back Panel (G) with Large Shelf (B) and secure the cam lock.




Align Left Panel (C) and Right Panel (D) with the shelves and secure all the cam locks.



Place Top Panel (J) onto the top of the unit and secure the cam locks. With assistance, lift the unit upright.





Cover all cam locks using Cover Caps (5).



Assistance is recommended for moving furniture.


**WARNING:** Check for pipes and electrical wiring before drilling.

**IMPORTANT:** The included wall anchor is suitable for drywall. Select a drill bit that is suited for your wall material and is smaller than the wall anchor; if the drill bit is too large, the tipover restraint system will be faulty. If in doubt about installing the tipover restraint, consult a certified professional.

Carefully measure and mark the location of screw installation and pilot holes before drilling. Measure twice, drill once!

## **Tipover System Installation**

- Ensuring it is flush with the back of the side panel, and approximately 95mm from the top of the unit, install one Corner Brace (6) to Left Panel (C) using one M6 x 9/16" Screw (7). Repeat this step to install the second brace to Right Panel (D).
- Place the unit against the wall and use a pencil to mark the position for drilling the pilot holes.
- · Move the unit away from the wall.
- Drill the pilot holes to the depth of the wall anchor.
- Insert two Wall Anchors (9) into the pilot holes, ensuring the openings are flush with the wall.
- Align the unit with the wall anchors and use two 5/32" x 1" Screws (8) to secure the unit to the wall.



Page 6 / 7

# 🚹 SAFETY STATEMENTS & WARNINGS 🗘

- · For indoor use only.
- This product is for residential use only; institutional or commercial use will automatically void the warranty.
- Ensure all fittings are tight before use. Periodically check fittings to ensure they remain tight.
- Only use this unit on a flat, level surface.
- · Never sit, stand or climb on the unit.
- Never allow children to stand, climb, or hang on the shelves.
- Do not place hot items or liquids directly on the furniture.
- · Never use chemical cleaning products or polishes as doing so may damage the finish.
- Do not exceed the weight capacity of the furniture.
- Do not overload shelves as doing so may cause them to sag.
- Always place the heaviest items on the lowest shelves.
- Never put a television on this item.
- Avoid long-term exposure to sunlight.
- Avoid placing the unit near heating or cooling vents as forced air is very drying and can damage the unit.
- Do not use furniture as a writing surface without a padded barrier to protect the surface.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team directly through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.



Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Biblioteca Classic 10/2022 Page 7 / 7