



## Instructions for Jespet Pet Exercise Playpen

**WARNING:** For safety, remove leash and collar before allowing pet to enter the playpen

1. Starting Position.



2. Fold the panel to the right of the elastic band inward. Be sure to keep the band exposed.



3. Fold the door panel to its left neighbor panel. Please note the flaps at the top and bottom need to be extended for panels to fold properly.



4. Fold the rest panels accordingly to make an "M" shape.



5. Once folded flat, wrap the elastic band around the folded playpen and then put all the parts into carrying bag for storage & transport.



If you have any problems with assembly or questions, please contact us via our e-mail: [support@jespet.com](mailto:support@jespet.com)