25935 – K-MICROHL-6 Operating instructions & Precautions 07182203

Charging: This product is rechargeable. Please charge fully before first use to ensure optimal performance.

Pull the rubber power port cover back to access the charging port. Plug one end of the included charging cable into any USB power source such as a power cube, computer or vehicle port and the other into the charging port. Red lights change to green when charging is complete. Replace the port cover.

Operation: Repeatedly pressing the power switch cycles between high, medium and low white brightness modes, green light, red light, and off.

Long pressing the power button in any light mode activates the white turbo light mode. The light reverts to the previously selected light mode automatically after 30 seconds. If turbo was activated from off, the light reverts to high brightness after 30 seconds.

When using the light in any mode for more than 8 seconds, you can shut the light off by pressing the power button once without the need to cycle through all light modes.

The light rotates up to 180 degrees in 8 lockable positions to aim light where needed.

Clip On Installation: To use the light on the bill of a cap, remove the headband by pulling it through the slots on each side of the light. Slide the integrated light clip on to either the top or bottom of the bill depending on how you plan to aim the light. **Note:** Clip is tight to keep it in place.

The included headband adjusts easily to fit most head sizes and accommodates most hats and helmets.

Warning! This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions.