

26208 - K-PP3KAA-4 Operating instructions & Precautions 11152201

Operation: Repeatedly pressing the power button cycles between high, medium, low and nightlight brightness modes.

Charging a Smartphone: Although not rechargeable, this lantern can give your smartphone an emergency charging boost. Pull back the rubber port cover. Plug your smartphone's charging cable into the lantern and your phone's charging port. **NOTE:** Attempting to fully charge a phone will greatly reduce the runtime of this lantern.

Battery Replacement: Unscrew the battery compartment cover at the base of the lantern. Remove the expired batteries and replace them with 8 new AA alkaline batteries following the diagram. To replace the battery compartment cover, line up the 2 keyed holes in the lantern with the keyed inserts on the cover and turn clockwise to close. **CAUTION:** Do not cross thread. Do not over tighten.

Caution: Replace all batteries at the same time. Do not install batteries backwards, charge or put in fire. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) Batteries. This may cause batteries to leak or explode. Old or discharged batteries must be recycled or disposed of properly, according to local regulations.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions!