


Purchase Date: / / Order/Customer Reference Number: \_\_\_\_\_\_\_ Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <u>https://tiny.cc/SunnydazeWarranty</u> If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: <u>customerservice@sunnydazedecor.com</u>, or via our contact us page at <u>https://tiny.cc/SunnydazeContact</u>

# **TRUNK WITH HANDLES**

Carefully review assembly and care instructions before using this product. Save this document for future reference. Assemble components on a soft, clean surface to avoid scratching or damaging the finish.



## () HELPFUL HINTS

Sunnydaze Decor advises reviewing this manual fully, and assembling the unit soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning.

• •

### SAVE THIS MANUAL FOR FUTURE REFERENCE.

Sunnya	daze l	Decor

CR540

••

## INTRODUCTION

### Read the manual carefully to ensure you fully understand all use, care, assembly, and safety information.



Read this manual carefully and follow the assembly instructions in the order listed. Pay close attention to assembly drawings.



Regularly clean with a clean microfiber cloth to prevent dust accumulation.



Do not paint the unit.

Do not use abrasive materials or cleaners to clean the furniture.



Indoor use only.

Do not expose the furniture to heat or humidity.



When cleaning nearby the furniture, do not allow contact with water or cleaners as it may deteriorate the furniture.



Do not allow metal components to come in contact with water or cleaners as it may cause rust and staining.



Assemble on a soft, flat, clean, and dry surface.

Use a soft, protective barrier when assembling the furniture.

**TIP:** Use the box carton as a protective layer to separate and protect the parts from scratches and other damage during assembly.

Do not push or drag furniture as doing so may damage the unit.

Only move furniture when it is empty.

Always ask for help when moving furniture.





**Avoid Accidents** - Do not climb, sit or stand on the furniture.

Do not allow children to play on or inside the furniture.

Keep sharp objects away as they may scratch or damage the unit.

Do not use the furniture as a writing surface without a padded barrier.

## **MOTICE**:


Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

49.8 **110** 

#### Sunnydaze Decor

• • (

## COMPONENTS





TOOLS REQUIRED (not included)		
	Phillips Screwdriver	
	Rubber Mallet	

### 🚹 WARNING 🕂

**CHOKING HAZARD** — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

Α		Wood Dowel	18
В		M4.5x28mm Pan Screw	2
С		M4x16mm Bolt	4
D		Connector	19
Е	() <b>-</b>	Tack	6
F	Contraction of the second s	Handle Set	2
G		M3x16mm Flat Screw	8
н		M4.5x25mm Pan Screw	35
J		Hinge	2
К		M3.5x14mm Pan Screw	12
L	ja	Lid Support	2

#### Sunnydaze Decor


••

• •

## ASSEMBLY

### Carefully review all steps and fully understand assembly before beginning.

IMPORTANT: Take care not to over-tighten screws as doing so may crack the wood or strip the screw hole, causing a weak connection and reduced stability.




install three Connectors (D) into Back Panel (04).

Sunnydaze Decor


••


• •





Ensuring the bottom grooves align, secure two Side Panels (03) to Back Panel (04) using six M4.5x25mm Pan Screws (H).

Ensuring the angled mounting holes face the bottom, align Bottom Support Rail (06) with the back panel, as shown. **NOTE:** The support rail will be secured in Step 6.









Align the components of Handle Sets (F) with the side panels. Ensuring the handle plates remain straight, secure each handle set using two M4x16mm Bolts (C).

Align Cap Panel (02) with the dowels on the back panel. Secure the cap panel using five M4.5x25mm Pan Screws (H).

07/2023


• •

•••

Sunnydaze Decor

CR540

SunnydazeDecor.com




Lay Top (01) face-up on a clean, smooth surface.

Align two Hinges (J) with the indents on the top and mostly fasten them using six M3.5x14mm Pan Screws (K).


Turn the top over and align two Lid Support Rails approximately 5 inches (5in, 12.7cm) from each short edge of the top. Secure each support rail using three M4.5x25mm Flat Screws (H).

#### **STEP 11 K**: 6



Ensuring Top (01) is aligned with Cap Panel (02), secure the hinges to the cap panel using six M3.5x14mm Pan Screws (K).


Sunnydaze Decor	• • • • • • • •	SunnydazeDecor.com
CR540	07/2023	Page 8 / 10



Align the metal mounting plate of Lid Support (L) with the indents on the underside of the lid and secure using two M3x16mm Flat Screws (G).


Align the plastic mounting bracket, at an angle, with the indents on the inside of the trunk and secure using two M3x16mm Flat Screws (G).

**NOTE:** There are 3 indents on the side panels, this is a result of the manufacturing process so the panels are interchangeable (can be installed on the left or right side and still allow for proper alignment of the lid supports).




Use the sharp end of one of the tacks to make a small indent at the inside corner of cutout.

After tack placement has been marked, install tacks using a rubber mallet.



• •



Sunnydaze Decor

CR540

### 🚹 SAFETY STATEMENTS & WARNINGS 🕂

- Residential use only. Not for commercial or industrial use.
- For indoor use only.
- Ensure fittings are tight before use. Periodically check fitting to ensure they are tight.
- Only use this unit on a flat, level surface.
- Do not sit, stand or climb on the unit.
- Supervise children; never allow children to climb on or play in this unit as doing so may cause serious injury.
- Do not place liquids or hot items directly on the furniture.
- Never use chemical cleaning products or polishes as they may damage the finish.
- Do not exceed the weight capacity of the furniture.
- Never move the unit when items are inside, empty the unit before moving.
- Do not place the unit in direct sunlight.
- Avoid placing unit near heating or cooling vents as forced air is very drying and can damage the unit.
- Do not write on furniture without a padded barrier to protect the surface.

### Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team directly through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.

## **MOTICE**:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Sunnydaze Decor

|--|--|

• •