

Thank you for purchasing the Wondurdog Sink Faucet Shower Kit



Wondurdog gives back. When you buy a Wondurdog product we donate 10% of proceeds to **ThePetFund.com** *The Pet Fund* saves lives by helping pets and owners who can't afford veterinarian care get the care they need.

Included in sink faucet kit:

Storage bag







Recoil shower hose with washers (stretches to over 10 feet)



Faucet diverter
with washer
(US Standard, Regular Size,
15/16"-27 male threads
and 55/64"-27 female threads)

Alternative Faucet Adapters

Alternative Faucet Adapters

Additional included faucet adapter sizes:

- 3/4" 27 Female GHT x 55/64" 27 Male (Garden hose / laundry tub size)
- 13/16" 27 Male x 55/64" 27 Male
- 3/4" 27 Female x 55/64" 27 Male
- 13/16" 24 Female x 55/64" 27 Male
- 16.5M, 18.5M, 21.5M, 24M

If none of the adapters fit your faucet, contact us at

with washers (US Standard, Regular Size, support@wondurdog.com. We have more uncom

support@wondurdog.com. We have more uncommon adapters in stock. We will help determine your faucet size and send the proper adapter to you at no cost to you. (Please include photo of your faucet and faucet aerator.)

*IMPORTANT: If you leave the water on and the shower brush in the OFF position for an extended period of time, it can cause breakdown such as water leak, head burst, and water flowing backwards. ALWAYS turn the water off when finished using the product and leave the brush in the ON position.

You will need:

• Pliers and a cloth to tighten connections. If using pliers, always cover metal with a cloth to avoid scratches.

Set-up Instructions:

- See reverse side **OR** view a short instructional set-up video at wondurdog.com.
- If you have questions about installation of an irregular faucet, please contact us at support@wondurdog.com. We're here to help. REALLY!

Operating Instructions:

- 1. The faucet diverter has two modes:
 - a. When lever is in down position, water flows down like a regular faucet.
 - b. When lever is moved to horizontal position, water comes out of brush head.
- 2. Set faucet diverter lever to DOWN position.
- 3. Ensure switch on brush head is in OFF position, then turn on cold water half way. Water should flow down through aerator like normal usage.
- 4. Move lever up to horizontal position to build pressure, then switch brush head to ON position.
- 5. To temporarily stop water flow to brush head, move switch to OFF position.*
- 6. The brush head has two positions:
 - a. For more control on the direction of water and to prevent splashing, keep rubber shield in DOWN position.
 - b. For deep cleaning and to remove dirt and debris, flip the rubber shield to UP position.

Questions/Comments?

E-mail us at support@wondurdog.com
We'd love to hear from you!

We invite you to post pictures of your muddy puppy and/or your clean *Wondurdog* pup on social media



facebook.com/wondurdog



instagram.com/wondurdog