



4. While holding the tent, switch your grip from bottom to an upper one.
5. Turn the tent inwards, creating with no pressure, two circles.



6. Carefully place the folded circles on top of each other and align them.



7. Place the folded tent into the carry bag. Kindly ensure that the side with the net goes in first to avoid damage that might be caused by the zip.

 **ALPCOUR**

## **POP-UP PRIVACY TENT**

### **INSTRUCTIONS MANUAL**

---



Congratulations on the purchase of the Alpcour Pop-Up Privacy Tent. It offers a private, clean and accessible space for changing clothes or as a bathroom. The pop-up tent is suitable for both indoor and outdoor use – camping trips, beach, swimming pool, mountain or forest hikes.

**CAUTION:** In the setting up and folding of the tent, DO NOT APPLY FORCE. The use of force may damage the tent.

## EXTERNAL FEATURES


- 6.8ft Tall, suitable for an average height man.
- Large 48x48" width Inside area
- Shower hole, simply slide the hose or shower head through the hole.
- Removable rain fly
- Removable ground sheet
- Large mesh for better ventilation
- Silver coated polyester
- Towel hook
- Sand bags with ropes and stakes

## INTERNAL FEATURES


- Towel/clothes hanger
- Zippered Window for Air Circulation
- Lantern hook
- Storage pocket
- XL side pocket
- Toilet paper holder

## HOW TO FOLD UP THE TENT


1. Pull the side poles of the tent together and fold them towards each other.



2. Lay the tent on the ground and stand next to the broader side (the tent floor side).



3. Hold the sides of the tent and carefully fold it in half (DO NOT APPLY FORCE). Ensure the two ends are equal.



# HOW TO SET UP THE TENT


5. Attach the floor mat to the pop-up tent using the fasteners, with the blue side facing inward and black side facing the ground.
6. Place the tent upright at your desired location.
7. Secure it to the ground using the included tent pegs.




3

**Note:** The tent will pop open once it is out of the bag, hence ensure you are in an open space, at least 2.5 ft away from people or objects

1. Unzip the carry bag and pull out the compacted tent, while still maintaining your grip.
2. Release your grip. The tent should pop open to its full length.



3. Lay the tent on the ground
4. Lift one side of the tent up and use your other hand to fully open up the tent.



2