

Pizza oven set Owner's Manual Model: WPZ1





IMPORTANT SAFETY INFORMATION!

- ATTENTION! Place the grill on a level, horizontal, secure, heat-resistant surface before you fit the Fire Box Pizza Oven.
- ATTENTION! The Fire Box Pizza Oven becomes very hot and may not be moved during operation.
- Always have a fire extinguisher and a first-aid box ready to hand, so that you are prepared in case of an accident or fire.
- Do not use in enclosed spaces or rooms!
- Do not use under areas covered with a roof!
- Only use the Fire Box Pizza Oven at a safe distance (at least 1.5 m) from flammable material, e.g. furniture and wooden buildings.
- When handling the Fire Box Pizza Oven, wear appropriate protective gloves (against thermal risks), which conform to EN 407 (category II).
- Only use grill utensils with a long, heat-resistant handle to put on and to turn the food to be grilled.
- Do not clean the Fire Box Pizza Oven until it has completely cooled.
- Check the condition of the Fire Box Pizza Oven regularly. Damage to the Fire Box Pizza Oven can cause fires and injuries!

Risk of burns and accidents!

The Fire Box Pizza Oven is not intended to be used by persons (including children) with limited physical, sensory or mental abilities or lack of experience and/or lack of knowledge.

- ATTENTION! Keep away from pets and children!
- Children should be warned by their parents of the danger of fire and the heat of burning and hot objects.
- Point out the dangers to this group of people and have this group of people supervised by a person responsible for their safety.
- Any changes to the Fire Box Pizza Oven constitute a large risk to safety and are prohibited.
- In case of damage, repairs or other problems, contact our service department or an appropriately skilled person in your area. Do not carry out any unauthorised interventions yourself.
- Do not let children play with the packaging film or other small parts. Risk of suffocation!

Risk of burns!

The Fire Box Pizza Oven and the grill become very hot during use. Any contact with them can lead to serious burns.

- Do not leave children and pets unsupervised while the Fire Box Pizza Oven is in operation.
- Do not wear clothing with wide sleeves.
- Pay attention at all times and always take care of what you are doing. Do not use the Fire Box Pizza Oven if you lack concentration, are tired, or you are under the influence of drugs, alcohol or medication. A short moment of inattention can lead to serious injuries.

CARBON MONOXIDE HAZARD!

Do not operate the Fire Box Pizza Oven in enclosed and/or habitable spaces, e.g. in buildings, tents, caravans, motorhomes, boats. Risk to life due to carbon monoxide poisoning.

OUTDOOR USE ONLY!

Grill Use Safety

Incorrect storage can lead to rust. If you are not going to use the Fire Box Pizza Oven for a lengthy time, store the cleaned and dry Fire Box Pizza Oven in a dry room protected from the weather. If necessary, store the pizza stone separately.

- Unpack the Fire Box Pizza Oven carefully. Attention! The pizza stone is breakable.
- Place the pizza stone in the Fire Box Pizza Oven. Do not wet the pizza stone with water or soak it before use. Heat it up properly before use
- The Fire Box Pizza Oven can be used both on a gas-fired grill and on a charcoal grill.
- If using on a gas-fired grill, place the Fire Box Pizza Oven on the grill first before igniting the grill. If using on a charcoal grill, ignite the grill first before placing the Fire Box Pizza Oven on it.
 - If operating with a gas-fired grill, please adjust the flame setting according to the required temperature at the thermometer of the box.
 - Only use with grills that have a sufficiently large cooking grate. A minimum diameter of approx. 53 cm for round grills, a minimum size of approx. 50 x 45 cm for rectangular grills
 - To place/remove the pizza in/out of the Fire Box Pizza Oven and to remove the pizza stone, please insert the pizza peel carefully, to avoid damage.

Care and Maintenance



You can burn yourself, if you clean the Fire Box Pizza Oven before all the parts have completely cooled.

- Allow the Fire Box Pizza Oven to cool completely before you clean it or wear protective gloves (against thermal risks), which conform to EN 407 (category II).

Risk of damage!

Improper handling of the Fire Box Pizza Oven can lead to damage.

- Do not use aggressive cleaning agents, steel brushes, abrasives or other hard objects, which could scratch the surface of the housing and the pizza stone.
- Clean the parts by hand using standard washing-up liquid. In case of heavy or burnt in soiling, additionally use special grease-dissolving kitchen cleaners (follow the instructions of the respective manufacturer!).

Disposing of the Fire Box Pizza Oven

At the end of its life, never throw the Fire Box Pizza Oven in the normal household waste. Contact your public waste disposal authority to find out where the appropriate waste collection centre is.

Limited Warranty

Dong Fang Jun Ma Trade Co., Ltd.(hereafter, DFJM) warranties that this Product shall be free from defects in workmanship and materials, for a period of 1 Year from the date of original purchase. Our obligation under this warranty shall be limited to replacement of parts during the warranty period. Our liability shall not extend beyond replacement of parts, This warranty excludes, normal wear & tear such as paint loss, discoloration and rust on the Product and its parts or components, and any damage arising from any of the following: negligent use or misuse of the Product, use contrary to this User's Manual, or alteration by any one other than DFJM. All warranty coverage is void if this grill is ever used for commercial or rental purposes; this warranty is valid only in the USA. The warranty period of 1 year shall not be extended or renewed by the repair or replacement of parts or compensation for the Product. If your Product is defective or otherwise requires service or parts, please call DFJM Customer Service toll-free at MONDAY TO FRIDAY, between 8:30 a.m. and 4:30 p.m. CST. Consumer is responsible for shipping, handling and processing of warranty claims after 30 days of purchase date. As proof of Purchase, a copy of your original purchase receipt must accompany any service request,

LIMITATION OF REMEDIES AND LIABILITY

We shall not be liable for any incidental or consequential damages for breach of any express or implied warranty on its Product. Except to the extent prohibited by applicable law, any implied warranty or merchantability or fitness for a particular purpose on this Product shall be limited to the duration of the above warranty. Neither us nor anyone else who has been involved in the creation, production, or delivery of the Product shall be liable for damages of any type, including but not limited to any lost profits, lost savings, loss of anticipated benefits, or other incidental or consequential damages which may arise out of the purchase, use, or inability to use the Product, whether arising out of contract, negligence, strict tort, or under any warranty, or otherwise, even if you have been advised of the possibility of such damage or any other claim by any other party. Our liability for any breach of warranty shall be limited to repair or replacement of the defective part or parts as described above. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The above warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Thank you for purchasing this product! If you have questions about the assembly or operation of this product, are missing parts, or have defective parts, please e-mail us at:

customerservice@dongfangjm.com

Or, call us toll free (M-F 8:30am to 4:30pm Central Time) at:

1-866-273-2284

Manufactured by: Dong Fang Jun Ma MADE IN CHINA