



CARE AND MAINTENANCE

Dust with a dry cloth. Do not use abrasive cleaner. Use glass cleaner to clean surface of table top.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION		QUANTITY
A	Seat Part		1X
B	Front Leg-L		2X
C	Read Leg-S		2X
H1	Screw		8X
H2	Spring Washer		8X
H3	Flat Washer		8X
H4	Allen Key		1X



Model#PAT4028A
Product Dimenions: W25.2xD24.4"D x 29"H








PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 8 minutes.

Tools Required for Assembly (included): Allen Key

		
STEP1 PLACE SEAT PART (A) FACE DOWN ON A SMOOTH SURFACE	STEP2 INVERT FRONT LEGS (B) AND ALIGN HOLE TO THREAD OPENING OF SEAT PART (A)	STEP3 PUT THE WASHERS ON THE BOLT IN THE ORDER SHOWN IN THE PICTURE
		
STEP4 USE SCREW (H1) AND SECURE BOLTS (H4) TIGHTLY	STEP5 REPEAT STEPS 3-4 FOR THE REAR LEGS (B) AS INDICATED IN PICTURE ABOVE	