




RentACoop®



TRANSFORM
ANY CONTAINER
INTO A WATERER




DIY
series

THE ORIGINAL AUTO-FILL CUP

NOW WITH CUP INSERTS FOR EASY-CLEANING!

IMPORTANT INFORMATION

You **MUST** remove the old water source before introducing a new watering system!




PLACEMENT OF WATERING SYSTEM

Watering system must be hung or placed on the edge of a stand to ensure full extension of the cups so that the cups do not touch the ground. Works best if top of cups are level with your smallest animals' shoulders.

INSTRUCTIONS


1. Measure and mark drilling holes 1" from the bottom of your container.

2. Create the hole(s) using a $\frac{3}{8}$ " drill bit (not provided).



3. Manually screw the Auto-fill Cup (with the gasket attached) into the drilled hole and turn clockwise by the elbow until tight.*

4. Attach the wingnut to the exposed threads of the elbow on the inside of the container.



*Gasket stays on the outside of the container.



RentACoop®

QUESTIONS?

CONTACT OUR
EGG - SPERTS

info@rentacoop.com

1 800-642-3571

M-F 9-5 EST

SHARE YOUR SETUP WITH
RENTACOOPT'S CHICKEN
COMMUNITY ON AMAZON!

