
32oz & 64oz Drinker

with RentACoop[®] Horizontal Nipple and Auto-fill Cup Drinking Attachments



X

UM-X8RN-25MU REV 23.09

TABLE OF CONTENTS	
PACKAGE CONTENTS	3
HORIZONTAL NIPPLE	4
BENEFITS	4
SETUP	4
MAINTENANCE	
AUTO-FILL CUP	
BENEFITS	6
SETUP	6-7
MAINTENANCE	8
CONTACT INFORMATION	BACK
	COVER

PACKAGE CONTENTS



When introducing a new type of waterer to your animals, completely remove the previous water source and replace it with the new waterer in the same location.

The position of the drinker depends on the height of your animal. We do not provide an exact measurement as all animal sizes vary. Please use your best judgement when installing.

For more information about this product, scan the QR code to view detailed instructions, watch tutorials, and more



HORIZONTAL NIPPLE

BENEFITS

Perfect for use in freezing temperatures when paired with a heating source/waterer deicer*

Low-maintenance — no dirty water bowls to clean


Training your chickens to use the nipples is easy

*Heating source not included and is sold separately. For safety, please follow the directions that come with your heating source/waterer deicer

TIP FOR WINTER-USE: We recommend removing the Dribble Dish from horizontal nipple so that water doesn't pool and freeze in it. The dribble dish snaps on and off.

SETUP





BENEFITS

Perfect for use in warm weather and non-freezing temperatures


Chickens can dip their wattles in the cups to cool off on hot days

Suitable for cross-beaks

Water is visible to chickens

Requires absolutely no training

SETUP



1. Hold the **DRINKER** on the outside of the cage and screw the cup into the drinker from the inside.



2. Secure the drinker to the cage-wire using the SPRING CLIP.



MAINTENANCE :

Note: To prolong the life of your drinker, we recommend washing the entire drinker at least once a week.

The bottle and lid are dishwasher-safe, top rack only. Disassemble drinker before cleaning.

CLEANING THE CUP-INSERT



Remove the insert, empty any debris and return the insert back to the cup.


USING THE EASY-CLEAN PLUG



The small silicone plug that is located underneath the lid can be removed and is used to stop the flow of water so that you can easily unscrew, move, and clean your cup without creating a mess.



1. Remove the **PLUG** from the lid and insert the plug into the hole at the bottom of the inside of the container.




2. Unscrew the drinking attachment by its elbow.




 After you are done unscrewing, moving, and/or cleaning, re-install the drinking attachment back onto the drinker before removing the plug. Return the plug to the lid to store for safe-keeping.

- Clean and wipe any dirt or debris from the cup.
- Pry one side of the tabs on the base to release the small plastic nodule out of its tab. Be careful not to break the nodules off.



- There is a load-spring so make sure to take the base off slowly. Once you release the first nodule, the second tab will come off easy.
- Check that all water spouts are clean of debris. You can use a toothpick if clogged.







v. 202308