

WINDOW AIR CONDITIONER COVER

Protects air conditioner from damage caused by freezing water and debris. Helps save energy by preventing cold drafts from entering through the unit.

Easy to Use:

1. Place cover over unit as shown.
2. Fit the sewn-in elastic corners to the bottom front corners of the unit.
3. Overlap the elastic straps under and around the unit and fasten hook on elastic strap into ring to complete installation.

WARNING: Damage to air conditioner may occur if it is operated while cover is on unit. Remove cover before operating system.

CUBIERTA PARA AIRE ACONDICIONADO DE VENTANA

Protege al aparato de aire acondicionado contra daño que provoca el agua helada y desechos. Ayuda a ahorrar energía evitando que las corrientes de aire pasen a través de la unidad.

Fácil de usar:

1. Coloque la cubierta sobre la unidad como se muestra.
2. Ajuste las esquinas elásticas cosidas a las esquinas delanteras de la parte inferior de la unidad.
3. Superponga las correas elásticas debajo y alrededor de la unidad y ajuste el gancho a la correa elástica dentro del anillo para finalizar la instalación.

ADVERTENCIA: El aire acondicionado puede sufrir daños si se pone en marcha mientras la cubierta está sobre la unidad. Retire la cubierta antes de poner en marcha el sistema.



QUESTIONS? | PREGUNTAS?
800.654.8454

MDBUILDINGPRODUCTS.COM

