

FRASER HILL FARM®

58" Dancing Mrs. Claus w/ Apron



Who's helping Santa and dancing along the way? Mrs. Claus, that's who! Our dancing Mrs. Claus, from Fraser Hill Farm, will dance right into your heart as she helps you greet your family, guests, or customers.

Standing 58 inches tall and holding a small sack filled with goodies, she will be a delightful addition to your holiday decor in any home, office, or store. When motion is detected, she will move her arms and sway her body to the music.

Dressed in a festive white apron over a red velvet dress with a coordinating mob cap, her friendly face and warm smile will fill you and yours with holiday cheer! She'll look perfect standing next to your Christmas tree.

- Motion-activated dancing Mrs. Claus with music
- Motion sensor triggered from 1.5 to 5 feet
- Music speaker and volume knob located on base
- Enjoy animation without music via switch on base
- Recommended for indoor use only
- Assembly required - Collapsible for easy storage
- 1-year warranty

Model Number	UPC	Dimensions	Description
FAMC058D-27RED	192487081082	15" D x 21" W x 58" H	58" Dancing Mrs. Claus w/ Apron

www.FraserHillFarm.com