
Haunted Hill Farm



Haunted Hill Farm



Model	Description	Battery Operated or Plug In	Color	Lit/Unlit	UPC
HH024TINWR-5BL	24-In. Spooky Tinsel Wreath	Battery Operated	Black	Warm White LED	840148707726
HH024TINWR-5MLT	24-In. Spooky Tinsel Wreath	Battery Operated	Purple/ Black	Warm White LED	840148707733
HH036TINTR-5BL1	3-Ft. Spooky Tinsel Tree	Plug In	Black	Warm White LED	192487338902
HH036TINTR-5BL2	3-Ft. Spooky Tinsel Tree	Plug In	Black	Orange LED	840148707757
HH036TINTR-5BL3	3-Ft. Spooky Tinsel Tree	Plug In	Black	Purple LED	840148707764
HH036TINTR-5ORN	3-Ft. Spooky Tinsel Tree	Plug In	Orange	Warm White LED	840148706910
HH036TINTR-5PUR	3-Ft. Spooky Tinsel Tree	Plug In	Purple	Warm White LED	840148706927
HH048TINTR-5BL1	4-Ft. Spooky Tinsel Tree	Plug In	Black	Warm White LED	840148707771
HH048TINTR-5BL2	4-Ft. Spooky Tinsel Tree	Plug In	Black	Orange LED	840148707788
HH048TINTR-5BL3	4-Ft. Spooky Tinsel Tree	Plug In	Black	Purple LED	840148707795
HH048TINTR-5ORN	4-Ft. Spooky Tinsel Tree	Plug In	Orange	Warm White LED	840148706934
HH048TINTR-5PUR	4-Ft. Spooky Tinsel Tree	Plug In	Purple	Warm White LED	840148706941
HH072TINGL-5BL	6 Ft. Spooky Tinsel Garland	Battery Operated	Black Purple	Warm White LED	840148707801
HH072TINGL-5BL1	6 Ft. Spooky Tinsel Garland	Plug In	Black	Warm White LED	840148707818
HH072TINGL-5MLT	6 Ft. Spooky Tinsel Garland	Battery Operated	Purple/ Black	Warm White LED	840148707825