



Part Reference

A	F11830
B	F11831
C	F11832



A 8 ea
End connector



B 4 ea
Long Shelf



C 12 ea
Vertical Pole

No tools required.

STEP 1:

- Insert long shelf (**B**) into two end connectors (**A**).

STEP 2:



- Working from the bottom up, insert 4 vertical poles (**C**) into top of end connectors (**A**).
- Repeat step 1 for second shelf.

STEP 3:

- Insert bottom of end connectors (**A**) of assembled shelf onto end of vertical poles (**C**).
- Repeat these steps for each additional shelf.

Note:

All metal parts must be inserted firmly and completely into the plastic parts.



8680 Swinnea Road • Suite 103 • Southaven, MS • 38671

NEED HELP? For help with assembly, or if you are missing a part, please call Whitmor's Consumer Care Team, 1-888-944-8667 between 8 a.m. and 4:30 p.m. (Central Standard Time) Monday through Friday. Or email: help@whitmor.com. Visit us online at www.whitmor.com