

AUTOMOTION™ | Shape-Shifting Robot RC Car

Instruction Manual | MODEL NO:TOY-ROBOCAR

Thank you for choosing our product! Please read this instruction manual carefully before using.

For Ages 6+

FIGURE A

USB Charging Cord



Rechargeable Battery



FIGURE B

Car Battery Compartment





FIGURE C

Battery Placement



FIGURE D



BATTERY INSTALLATION

REMOTE CONTROL

1. Remove the screw holding the battery compartment door located on the rear of your remote control.
2. Remove the battery compartment door.
3. Insert two AA batteries according to the polarity information located in the compartment; make sure the (+) and (-) poles of the batteries are positioned correctly.
4. Replace the battery compartment door and screw, and tighten screw completely to lock in place.

AUTOMOTION CAR

1. A rechargeable battery is included for use in the AutoMotion (Figure A). To charge, connect the cord of the battery into the USB cord (Figure A) included with your vehicle. Insert the USB cord into a computer or wall adapter. While charging, a red LED will illuminate on the USB end of the cord; when completely charged, the light will turn off.
2. Remove the screw holding the battery compartment door located on the bottom of your car; and remove the battery compartment door.
3. Insert the end of the rechargeable battery's cord into the plug located in the battery compartment (Figure B). Place the battery into the compartment (Figure C).
4. Reinstall the battery compartment door; make sure the cord and battery are completely in the compartment. Once installed replace and re-tighten the lock screw.

OPERATION

1. The car can be turned ON by moving the activation switch to ON position located on the bottom of your car. The car can be turned OFF by moving the switch to the OFF position.
2. Turn the remote control ON by pressing either on the One Push buttons. A red LED will flash until it pairs with AutoMotion vehicle; once paired, the light will turn off. NOTE - if you do not pair your remote, the light will continue to flash until either paired or the remote automatically shuts down.
3. Drive the car by operating the sticks of the remote control. You should use your car on a clear flat surface with enough space to maneuver and transform your vehicle.

NOTE: Your vehicle and remote use 2.4 GHz technology, allowing multiple vehicles to be used separately in the same room without interference. To do so, activate and pair one vehicle and one remote and then do the same for each other vehicle/remote sequentially.

REMOTE CONTROL FUNCTIONS: (Figure D)

1. Use the One-Push Demonstration button to watch your car move and transform. The indicator light will turn on once demonstration has started and turn off once it has stopped. When using this button, DO NOT use other controls until the demonstration is finished.

2. Use the One-Push Transformation button to transform your car to a robot. Push and hold the button until it is a robot; push and hold again to change it back to a car.
3. Use the toggle control on the left to move your car forward by pushing UP, and backward by pushing DOWN.
4. Use the toggle control on the right to turn your car to the right by pushing it to the RIGHT, and to the left by pushing it to the LEFT.

WARNINGS:

- Not suitable for children under 6 years due to detachable small parts.
- Installation of the battery should ALWAYS be done by an adult.
- Keep fingers, hair and loose clothing away from the vehicle's tires and wheels.
- Don't pick up the vehicle while in motion.
- Don't put your vehicle or transmitter near any source of heat.
- Don't operate your vehicle in dangerous places.
- Avoid driving on sand and loose gravel.
- Don't let the vehicle get wet. Don't run through water or operate in the rain.
- Do not disassemble the vehicle or remote control.
- If the vehicle is damaged and any broken parts are exposed, the vehicle should not be used.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces.
- DO NOT attempt to transform car manually by hand. ALWAYS use transformation button on remote control to transform car to and from robot.
- Only use the USB cord and battery included with your AutoMotion.
- Only use the USB cord included with your AutoMotion to charge the rechargeable battery.

BATTERY SAFETY:

- Do not mix old and new batteries.
- Do not swallow batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Batteries must be recycled or disposed of properly.

FCC INFORMATION

This device complies with part 15 of the FCC Rule. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to: *Flipo Group*

613 First Street
La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



WARNING:

**CHOKING HAZARD - small parts,
Not for children under 3 years.**



Distributed by Flipo Group Limited La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com • Fax: (815) 223-9266

MADE IN CHINA