

Battery Instructions

Battery Installation – Should the UV light become dim/not function, the batteries should be replaced. To do so, open the battery compartment by grasping the nub located at one end of the wand and twist counter clockwise. Turn the wand upside down and remove the old batteries contained in a clear plastic sleeve. Remove the old batteries from the sleeve; DO NOT DAMAGE OR DISPOSE OF the sleeve. Insert 4 new AG3 button cell batteries in the sleeve with the negative (-) anode pushed in 1st and all four batteries aligned in the same polarity. Insert the battery stack into the wand with the negative (-) anode inserted first – the positive (+) should be visible when you look into the battery compartment. Replace the top by turning clockwise.

Use - The wand will illuminate when the button located on its side is pressed.

Once illuminated, simply draw on the white belly of your AniMate.

The glow effect is best viewed in a darkened environment.

PLEASE NOTE - the glow effect WILL NOT work in environments with ambient outdoor light.

WARNING - DO NOT shine/point the UV light into your eyes/face or others eyes/face.

CAUTION

- 1. Never disassemble or otherwise alter or change the product.
- 2. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries, cause batteries to leak or damage the product.
- 3. Do not mix old and new batteries.
- 4. Do not dispose of batteries in fire.
- Batteries should be recycled.

30 DAY WARRANTY

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to: Flipo Group Limited, 613 1st Street La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Distributed by Flipo Group Limited, La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com • Fax: (815) 223-9266 MADE IN CHINA



Battery Instructions

Battery Installation – Should the UV light become dim/not function, the batteries should be replaced. To do so, open the battery compartment by grasping the nub located at one end of the wand and twist counter clockwise. Turn the wand upside down and remove the old batteries contained in a clear plastic sleeve. Remove the old batteries from the sleeve; DO NOT DAMAGE OR DISPOSE OF the sleeve. Insert 4 new AG3 button cell batteries in the sleeve with the negative (-) anode pushed in 1st and all four batteries aligned in the same polarity. Insert the battery stack into the wand with the negative (-) anode inserted first – the positive (+) should be visible when you look into the battery compartment. Replace the top by turning clockwise.

Use - The wand will illuminate when the button located on its side is pressed.

Once illuminated, simply draw on the white belly of your AniMate.

The glow effect is best viewed in a darkened environment.

PLEASE NOTE - the glow effect WILL NOT work in environments with ambient outdoor light.

WARNING - DO NOT shine/point the UV light into your eyes/face or others eyes/face.

CAUTION

- 1. Never disassemble or otherwise alter or change the product.
- 2. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries, cause batteries to leak or damage the product.
- 3. Do not mix old and new batteries.
- 4. Do not dispose of batteries in fire.
- 5. Batteries should be recycled.

30 DAY WARRANTY

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to: Flipo Group Limited, 613 1st Street La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Distributed by Flipo Group Limited, La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com • Fax: (815) 223-9266 MADE IN CHINA