

CONSTRUCTOSAUR™ DRAGON

Instruction Manual | MODEL NO:TOY-CON-DRAGON

Thank you for choosing our product! Please read this instruction manual carefully before using.
For Ages 3+

FIGURE 1



FIGURE 2



BATTERY INSTALLATION

1. Use a Phillips-head screwdriver to remove the screw holding the battery compartment door in place located on the belly of the Constructosaur.
2. Install 3 x AAA batteries according to the polarity diagram located in the battery compartment.
3. Close the lid, reinstall the lock screw and tighten.

ASSEMBLY

1. Connect the tail to the body by pushing onto the corresponding round socket located on the rear of the Constructosaur's body. Once connected, tighten the tail's integrated plastic screws tightly.
2. Connect the wings to the sockets located on the shoulders of the Constructosaur. **(FIG.1 A)**
3. Connect the legs to the body by pushing onto the corresponding round sockets and pegs located on the side of the Constructosaur's body. Once connected, tighten the tail's integrated plastic screws tightly. **(FIG.1 B)**

OPERATION

1. The power switch is located below the Constructosaur's head.
2. When positioned to the far left, the switch is in the OFF position.
3. Moving the switch to the middle position will activate the Constructosaur's internal LED lights, movement and vapor- the legs and mouth move, and water vapor will be emitted.
4. Moving the switch to the far right will activate Constructosaur's internal LED lights sound and vapor - the legs and mouth move, and a roar will sound and water vapor will be emitted.
5. To use the vapor function, water must be poured into your Constructosaur's head. First, fill the included small bottle with water; for best results use filtered or distilled water. Next, open the compartment located on the top of the Constructosaur's head and slowly pour in water. **(FIG. 2)** After filling, close the compartment door.

WARNINGS:

- Not suitable for children under 3 years due to detachable small parts.
- Installation of the battery should ALWAYS be done by an adult.
- CAUTION BRIGHT LIGHTS: Do not stare into light.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces.

BATTERY SAFETY:

- Do not mix old and new batteries.
- Do not swallow batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Batteries must be recycled or disposed of properly.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



Distributed by Flipo Group Limited La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com • Fax: (815) 223-9266

MADE IN CHINA