

Please read this instruction manual carefully before using.

- For Ages 6+
- Adult guidance is strongly recommended.

### CONTENTS:

- 1 x Mist Master Stunt Car
- 1 x Remote Control
- 1 x USB Battery Charging Cable
- 1 x Mini Phillips Head Screwdriver
- 1 x Water Fill Bottle

Figure A - Remote Control Buttons





Figure B - Operation



## BATTERY INSTALLATION & CHARGING

### Inserting the Remote-Control Batteries

1. Use the included Phillips head screwdriver to loosen the safety screw located on the battery compartment cover.
2. Remove battery cover using integrated locking tab.
3. Insert two AA batteries according to the polarity graphic inside the battery compartment. Replace the cover and tighten the screw.

### Charging the Remote-Control Car Batteries

1. Make sure the On/Off switch is in the Off position on the car.
2. Use included Phillips head screwdriver to loosen the safety screw located on the battery compartment cover located on the front of the car.
3. Remove battery cover by pushing in the direction of the "Open" arrow marked on the cover.
4. Remove rechargeable battery from the battery compartment, depress battery connector safety lock, and separate wire connectors.
5. Plug the USB charging cables into a USB port or a USB AC adapter and insert the adapter into an electrical outlet.
6. Connect battery wire connector to the connector on the USB cable. The red light on the charging cable will light when charging. When batteries are fully charged, the light will turn off.
7. When battery is fully charged, disconnect the battery connector from the USB charging cable, and unplug the cable from the power source.
8. Reconnect battery wire connector to the battery cable in the battery compartment, reinsert battery, replace battery compartment cover, and tighten the screws.

## FUNCTIONS

1. Move the toggle ON/OFF switch located on the top front of the vehicle to the ON position. The blue lights on the car will flash until the remote control is turned ON.
2. Move the toggle ON/OFF switch on the remote control to the ON position. When the remote is connected, the lights will cycle, flash, and fade through all color combinations.

**Note:** If the car is not turned On, the red indicator light on the remote will flash.

## **REMOTE-CONTROL BUTTONS - FIGURE A**

**Auto Demonstration Button** – the Mist Master will automatically cycle through a variety of stunt features.

### **Light Button**

1. Press and hold for approximately 1 second to turn the lights OFF.
2. Press and hold approximately 1 second to turn lights ON.

### **Using the Misting Feature**

1. Fill the included water fill bottle with purified water.
2. Remove the water reservoir cap from the top center of the car.
3. Place the water fill bottle nozzle in the spray reservoir hole and squeeze the water bottle gently to fill.
4. Remove the water bottle and replace the cap.
5. Quick press the Light button once to turn the Red Misting light and the Misting function ON.
6. Quick press the Light button a second time to turn the Red Misting light and the Misting function OFF.

**Left Joystick** – Left wheel forward and backward.

**Right Joystick** – Right wheel forward and backward.

## **OPERATION - FIGURE B**

Push both joysticks upward and the car will move forward.

Push both joysticks downward and the car will move backward.

Push the left joystick up and the car will turn right.

Push the right joystick up and the car will turn left.

Left joystick up/Right joystick down – spin clockwise, open, stand, and stunt spin.

Right joystick forward/Left joystick backwards - spin counterclockwise, open, stand, and stunt spin.

## **⚠ WARNINGS:**

- Not suitable for children under 6 years of age.
- Installation of batteries should ALWAYS be done by an adult.
- Keep fingers, hair and loose clothing away from the vehicle's tires and wheels.
- Don't pick up the vehicle while in motion.
- Don't place your vehicle or remote control near any source of heat.
- Don't operate your vehicle in dangerous places.
- Avoid operating on sand, gravel or other loose surfaces.
- Don't let the vehicle get wet. Don't run through water or operate in the rain.
- Do not disassemble the vehicle or remote control.
- If the vehicle is damaged and any broken parts are exposed, the vehicle should not be used.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces. Operation on pliable surfaces such as carpeting or rugs may prevent some stunts.

## **BATTERY CARE & SAFETY:**

- Do not overcharge the rechargeable battery. When the battery is fully charged, immediately remove it from the charger.
- Only use the rechargeable battery included with your Mist Master.
- Only use the USB cord included with your Mist Master to charge the rechargeable battery.
- Do not charge battery near flammable materials or leave unattended during charging.
- Charging should always be supervised by an adult.
- Failure to insert batteries in the correct polarity may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per manufacturer's recommendations.

## **30 DAYS LIMITED WARRANTY:**

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

*Flipo Group  
613 First Street  
La Salle, IL 61301*

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



Manufactured by Flipo Group Limited La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com

**MADE IN CHINA**