





Please read this instruction manual carefully before using.

- For Ages 8+
- Adult guidance is strongly recommended.

CONTENTS:

2 x Battle Jets
2 x Rider Action Figures
2 x Remote Control
2 x USB Battery Charging Cable
2X Rechargeable Battery

Figure A - Remote Control Buttons**Figure B - Operation****BATTERY INSTALLATION & CHARGING****Inserting the Remote-Control Batteries**

1. Use a Phillips head screwdriver to loosen the safety screw located on the battery compartment cover on the bottom of the remote. The screws are not completely removable for safety.
2. Remove battery cover using integrated screw tab.
3. Insert two AAA batteries according to the polarity graphic inside the battery compartment. Replace the battery compartment cover and tighten the screw.
4. Repeat above steps for second remote control.

Charging the Battle Jet Batteries

1. Make sure the On/Off switch is in the Off position on Battle Jet.
2. Use a Phillips head screwdriver to loosen the safety screw located on the battery compartment cover of the Battle Jets. The screws are not completely removable for safety.
3. Remove battery cover by pushing the safety tab in the direction of the "Open" arrow marked on the cover.
4. Remove rechargeable battery from the battery compartment, depress battery connector safety lock, and separate wire connectors.
5. Plug the USB charging cable into a USB port, or a USB AC adapter and insert the adapter into an electrical outlet.
6. Connect the battery connector to the connector on the USB cable. The red light on the charging cable will light when charging. When batteries are fully charged, the light will turn Off.
7. When battery is fully charged, disconnect the battery connector from the USB charging cable, and unplug the cable from the power source.
8. Reconnect battery to the battery cable in the battery compartment, reinsert battery, replace battery compartment cover, and tighten the screw.
9. Repeat above steps for second Battle Jet battery.

FUNCTIONS

1. Move the toggle On/Off switch on the bottom of the Battle Jet to the On position. The red light on the Battle Jet's windshield will flash. **(Figure A)**
2. Move the toggle On/Off switch on the remote control to the On position. The red indicator light on the remote will flash if Battle Jet is not turned On. When the remote is connected to the Battle Jet the remote light will turn Off. **(Figure A)**
3. Place rider action figure on seat of the Battle Jet, aligning the peg with the hole in the seat and press down to activate ejection feature, then place the rider's hands on the handlebars.
4. Repeat the above steps for the second remote control and Battle jet/rider.

TRIM CONTROL ADJUSTMENT

After use, the wheels of your Battle Jets may become misaligned. Should this occur, use the trim control located on the bottom of your vehicles. If the wheels are pulling to the right while operating, move the arrow to the right. If the wheels are pulling to the left while operating, move the arrow to the left. **(Figure A)**

Remote Control Buttons - Figure B

Left joystick: Forward/Backward - Push the left joystick up and the vehicle will move forward. If you continue to push the joystick up the vehicle will continue to move forward.

Push the left joystick down and the vehicle will move backward. If you continue to push the joystick down the vehicle will continue to move backward.

Right joystick: Turning - Push the right joystick to the left to turn left or to the right to turn right. If you continue to push the right joystick in either direction, the vehicle will continue to turn in that direction, allowing for continuous circles in that direction.

Note: The design of your Battle Jets only allows for turning when moving forward or backward.

Ejection feature - a direct hit to the trigger buttons on the sides of the Battle Jet will activate and eject rider from the Battle jet.

WARNINGS:

- Not suitable for children under 8 years of age.
- Installation of batteries should ALWAYS be done by an adult.
- Keep fingers, hair and loose clothing away from the vehicle's tires and wheels.
- Don't pick up the vehicle while in motion.
- Don't place your vehicle or remote control near any source of heat.
- Don't operate your vehicle in dangerous places.
- Avoid operating on sand, gravel or other loose surfaces.
- Don't let the vehicle get wet. Don't run through water or operate in the rain.
- Do not disassemble the vehicle or remote control.
- If the vehicle is damaged and any broken parts are exposed, the vehicle should not be used.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces. Operation on pliable surfaces such as carpeting or rugs may prevent some stunts.

BATTERY CARE & SAFETY:

- Do not overcharge the rechargeable battery. When the battery is fully charged, immediately remove it from the charger.
- Only use the rechargeable battery included with your Battle Jets.
- Only use the USB cord included with your Battle Jets to charge the rechargeable battery.
- Do not charge battery near flammable materials or leave unattended during charging.
- Charging should always be supervised by an adult.
- Failure to insert batteries in the correct polarity may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per manufacturer's recommendations.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

*Flipo Group
613 First Street
La Salle, IL 61301*

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



Manufactured by Flipo Group Limited La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com

MADE IN CHINA