



# FLIPSTER™ CHAMELEON COLOR SELECT

## ULTRA-STUNT RC GLOW CAR | Instruction Manual

Please read this instruction manual carefully before using.

- For Ages 3+
- Adult guidance is strongly recommended.

FIGURE A





FIGURE B



## BATTERY INSTALLATION

### REMOTE CONTROL

1. Loosen and remove the lock screw located on the rear of your remote control and remove the battery compartment lid.
2. Insert 2 AA batteries according to the polarity information located in the compartment; make sure the (+) and (-) poles of each battery are positioned correctly.
3. Replace the battery compartment door and screw; tighten screw completely to lock in place.

### CAR

1. Loosen the lock screw located on the underside of your Flipster until it stops. Lock screw is not fully removable for safety. Remove the battery compartment lid.
2. Insert 3 AA batteries according to the polarity information located in the compartment; make sure the (+) and (-) poles of each battery are positioned correctly.
3. Replace the battery compartment door and tighten screw completely to lock in place.

## OPERATION

1. The Flipster is activated by moving the red toggle switch located on the bottom of the vehicle to the ON position. To deactivate, move the switch to the OFF position. When first turned ON the car will cycle and flash through a combination of all color options.
2. Press the ON button on your remote to link to the Flipster. The light on the remote will flash matching the color of the car. Press the remote ON button to cycle through color choices. Your car will change to match the remote's color choice.
3. For competitive multi-vehicle play, your Flipster color can be chosen with the remote. Then follow the previous steps #1 and #2 to add additional Flipster Chameleon Stunt Cars.
4. Drive the car by operating the white buttons on your remote control (Figure A).

**SPINNING STUNT MOVES** – Your Flipster is capable of any number of spins, turns, wheelies and other stunts. To do so, simply move your Flipster backward or forwards while also pushing one of the buttons on the right side of the remote that make the front axle twist. Different combinations of pushing these buttons will create different tricks! (Figure B)

### GLOW-IN-THE-DARK FEATURES

The Flipster's wheel hubs, windshield and stunt wheels all glow in the dark. For this function to work, your Flipster must be exposed to bright light. For best results, expose to sunlight.

## **WARNINGS:**

- Not suitable for children under 3 years of age.
- Installation of batteries should ALWAYS be done by an adult.
- Keep fingers, hair and loose clothing away from the vehicle's tires and wheels.
- Don't pick up the vehicle while in motion.
- Don't place your vehicle or remote control near any source of heat.
- Don't operate your vehicle in dangerous places.
- Avoid operating on sand, gravel or other loose surfaces.
- Don't let the vehicle get wet. Don't run through water or operate in the rain.
- Do not disassemble the vehicle or remote control.
- If the vehicle is damaged and any broken parts are exposed, the vehicle should not be used.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces. Operation on pliable surfaces such as carpeting or rugs may prevent some stunts.

## **BATTERY CARE:**

- Failure to insert batteries in the correct polarity may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per manufacturer's recommendations.

## **FCC INFORMATION**

Appropriate marking shall appear on both the product and instruction manual.

Marking shall include,

- Model number(s): TOY-FLIP-GO-2PK, TOY-FLIP-RB-2PK, TOY-FLIP-GP-2PK, TOY-CHAMELEON-R, TOY-CHAMELEON-B

- "This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

Instruction manual shall include,

- "Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

- "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

FCC Radiation Exposure Statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.

## **30 DAYS LIMITED WARRANTY:**

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

*Flipo Group  
613 First Street  
La Salle, IL 61301*

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



Manufactured by Flipo Group Limited La Salle, IL

Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com • Fax: (815) 223-9266

**MADE IN CHINA**