



DINO TECH
BUILD-IT KIT
For Ages 5+

Parts list




Parts list




Note: Your Dino-Tech Build-It Kit comes packed in a secure robot case. To open, remove the two safety nuts on the sides by turning in the direction of the arrows on the nuts. Pull the end latches to remove the case cover and remove the Dino body, manual, decals, and parts bags from the case.

Battery installation

Note: Install batteries prior to assembly.
Make sure the power switch is in the OFF position.




1. Locate the battery compartment cover on the underside of the Dino's body.
2. Use a small Phillips head screwdriver to loosen the safety screw on the battery compartment cover. Screw is not fully removable for safety.
3. Insert 2 AAA batteries according to the polarity graphic inside the battery compartment; make sure the (+) and (-) poles of each battery are positioned correctly.
4. Replace the battery compartment cover and tighten the screw.



Assembly


Left Foot Assembly




Be aware of the direction of part **B2** posts. This part will not be secured in place until the bottom foot cover part **B5** is in place.

Insert **B2** through the hole in the top of foot. Turn foot over to ensure pins are resting in the provided receivers. Continue with assembly instructions.


Left Foot Assembly




Left Foot & Leg Assembly




Right Foot Assembly




Right Foot & Leg Assembly





Rib Cage Assembly







Tail To Body Assembly










Leg To Body Assembly












Arm Assembly




Back Assembly




Face Assembly





Face Assembly




Sticker installation











Operation

Locate the ON/OFF/TRY ME toggle switch on the top of the Dino. Move the toggle switch to the TRY ME mode position to activate the eyes and sound. In TRY ME mode the eyes and sound will work but the Dino will not walk.



Move the toggle switch to the ON mode position to activate all functions. While in ON mode you can press the eyes to turn off light and sound. Press a second time to turn light and sound back ON.
Automatic hibernation: If not used for approximately 3 minutes, to save battery life, the Dino will hibernate. Press and hold the eyes for approximately 2 seconds to wake him up.



WARNING

- Not suitable for children under 5 years of age.
- Installation of batteries should ALWAYS be done by an adult.
- Assembly should be supervised by an adult.
- Keep fingers, hair, and loose clothing away from the toy' s moving parts.
- Don't place your toy near any source of heat.
- Don't operate your toy in dangerous places.
- Avoid operating on sand, gravel or other loose surfaces.
- Don't let the toy get wet. Don't move through water or operate in the rain.
- Do not disassemble the vehicle or remote control.

BATTERY CARE

- Failure to insert batteries in the correct polarity may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- For best results, use alkaline batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of according to local, state, or federal regulations.

30 DAY LIMITED WARRANTY

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.
During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

Flipo Group
613 First Street
La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Distributed by Flipo Group Limited La Salle, IL
Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com
MADE IN CHINA

⚠WARNING
CHOKING HAZARD -
Small parts Not for children under 3 years.