



# MASSIMO




## **T-BOSS 550**

### PARTS MANUAL

## T-BOSS 550 PARTS MANUAL

### Frame




Ref.No.	Part Number	Description	Q'ty
1	48055	Frame	1
2	48063	Bracket, Air Cleaner	1
3	10140B	Bolt M6X12	12
4	48060	Cushion Support Component	1
5	10059	Bolt M8X25	4
6	10078	Bolt M8X30	2
7	11145	Nut M8	4
8	10783	Bolt M8X20	2
9	48086	Bracket, Radiator	1
10	11236	Bolt M8X16	2
11	48118	Heat Protection Plate, Rear Gearcase	1
12	11233	Nut M6	4
13	48061	Bracket, Fixed Hood	1
14	48062	Bracket, Instrument Panel	2
15	48056	Bracket, Rear Axle	1
16	11050	Bolt M10×1.25×110	4
17	10795	Nut M10	13
18	11237	Bolt M10×1.25×20	4
19	48064	Pipe, Rear Axle, Front	1
20	48065	Pipe, Rear Axle, Rear	1
21	48057	Bracket, Front Axle	1
22	11146	Bolt M10×1.25×90	1
23	10541	Bolt M10×1.25×30	2
24	11237	Bolt M10×1.25×20	4





## T-BOSS 550 PARTS MANUAL

### Front Fender




Ref.No.	Part Number	Description	Q'ty
1	48204	Removable Hood	1
2	482056g	Fixed Hood,White	1
2	482053l	Fixed Hood,Blue	1
2	482052h	Fixed Hood,Red	1
2	482057c	Fixed Hood,Vista Camouflage	1
2	482057e	Fixed Hood,Reality Camouflage	1
2	482057F	Fixed Hood,Conceal Camouflage	1
2	482054L	Fixed Hood,Orange	1
2	482055e	Fixed Hood,Army Green	1
2	482054M	Fixed Hood,Quick Sand	1
2	482059A	Fixed Hood,Gray	1
3	48316	Tapping Screw M5 x16	33
4	48253	Fast Disassembled Screw	2
5	48206	Battery Box	1
6	48269	Bolt M6X16	4
7	10783	Bolt M8X20	2
8	48314	Spring Nut M5	12
9	70960	Spring Nut M6	4
10	482076g	Fender Front,Lh, White	1
10	482073l	Fender Front,Lh, Blue	1
10	482072h	Fender Front,Lh, Red	1
10	482077c	Fender Front,Lh, Vista Camouflage	1
10	482077e	Fender Front,Lh, Reality Camouflage	1
10	482077F	Fender Front,Lh, Conceal Camouflage	1
10	482074L	Fender Front,Lh,Orange	1

10	482075e	Fender Front,Lh,Army Green	1
10	482074M	Fender Front,Lh, Quick Sand	1
10	482079A	Fender Front,Lh, Gray	1
12	482086g	Fender Front,Rh,White	1
12	482083l	Fender Front,Rh,Blue	1
12	482082h	Fender Front,Rh,Red	1
12	482087c	Fender Front,Rh,Vista Camouflage	1
12	482087e	Fender Front,Rh,Reality Camouflage	1
12	482087F	Fender Front,Rh,Conceal Camouflage	1
12	482084L	Fender Front,Rh,Orange	1
12	482085e	Fender Front,Rh,Army Green	1
12	482084M	Fender Front,Rh,Quick Sand	1
12	482089A	Fender Front,Rh,Gray	1

## T-BOSS 550 PARTS MANUAL

### Front Fender



Ref.No.	Part Number	Description	Q'ty
13	482116g	Lh Lower Front Mudguards,White	1
13	482113L	Lh Lower Front Mudguards,Blue	1
13	482112h	Lh Lower Front Mudguards,Red	1
13	482117c	Lh Lower Front Mudguards,Vista Camouflage	1
13	482117e	Lh Lower Front Mudguards,Reality Camouflage	1
13	482117F	Lh Lower Front Mudguards,Conceal Camouflage	1
13	482114L	Lh Lower Front Mudguards,Orange	1
13	482115e	Lh Lower Front Mudguards,Army Green	1
13	482114M	Lh Lower Front Mudguards,Quick Sand	1
13	482119A	Lh Lower Front Mudguards,Gray	1
14	482126g	Rh Lower Front Mudguards,White	1
14	482123L	Rh Lower Front Mudguards,Blue	1
14	482122h	Rh Lower Front Mudguards,Red	1
14	482127c	Rh Lower Front Mudguards,Vista Camouflage	1
14	482127e	Rh Lower Front Mudguards,Reality Camouflage	1
14	482127F	Rh Lower Front Mudguards,Conceal Camouflage	1
14	482124L	Rh Lower Front Mudguards,Orange	1
14	482125e	Rh Lower Front Mudguards,Army Green	1
14	482124M	Rh Lower Front Mudguards,Quick Sand	1
14	482129A	Rh Lower Front Mudguards,Gray	1
15	48209	Lh Upper Front Mudguards	1
16	48210	Rh Upper Front Mudguards	1
17	71959	Front Reflector Yellow (For US)	2








## T-BOSS 550 PARTS MANUAL

### Body, Fenders




Ref.No.	Part Number	Description	Q'ty
1	482306g	LH Upper Panel,White	1
1	482303L	LH Upper Panel,Blue	1
1	482302h	LH Upper Panel,Red	1
1	482307c	LH Upper Panel,Vista Camouflage	1
1	482307e	LH Upper Panel,Reality Camouflage	1
1	482307F	LH Upper Panel,Conceal Camouflage	1
1	482304L	LH Upper Panel,Orange	1
1	482305e	LH Upper Panel,Army Green	1
1	482304M	LH Upper Panel,Quick Sand	1
1	482309A	LH Upper Panel,Gray	1
1	48250	RH Upper Panel, Liner Panel	1
2	48314	Spring Nut M5	14
3	48316	Tapping Screw M5 x16	46
4	48249	LH Upper Panel, Liner Panel	1
5	482316g	RH Upper Panel,White	1
5	482313L	RH Upper Panel,Blue	1
5	482312h	RH Upper Panel,Red	1
5	482317c	RH Upper Panel,Vista Camouflage	1
5	482317e	RH Upper Panel,Reality Camouflage	1
5	482317F	RH Upper Panel,Conceal Camouflage	1
5	482314l	RH Upper Panel,Orange	1
5	482314M	RH Upper Panel,Quick Sand	1
5	482314M	RH Upper Panel,Quick Sand	1
5	482319A	RH Upper Panel,Gray	1
6	48250	RH Upper Panel, Liner Panel	1

7	48222	Side Panel Mounting Button	2
8	482326g	LH Lower Panel,White (Without a hole)	1
8	482323L	LH Lower Panel,Blue (Without a hole)	1
8	482322h	LH Lower Panel,Red (Without a hole)	1
8	482327c	LH Lower Panel,Vista Camouflage (Without a hole)	1
8	482327e	LH Lower Panel,Reality Camouflage (Without a hole)	1
8	482327F	LH Lower Panel,Conceal Camouflage (Without a hole)	1
8	482324L	LH Lower Panel,Orange (Without a hole)	1
8	482325e	LH Lower Panel,Army Green (Without a hole)	1
8	482324M	LH Lower Panel,Quick Sand (Without a hole)	1
8	482329A	LH Lower Panel,Gray (Without a hole)	1
9	70960	Spring Nut M6	2
11	485526G	RH Lower Panel,White(with hole)	1
11	485523L	RH Lower Panel,Blue(with hole)	1




**Body, Box**



Ref.No.	Part Number	Description	Q'ty
1	48242	Box Floor Cover	1
2	48145	Box Rear Panel Rubber Stopper	2
3	48241	Box Cover,R	1
4	48240	Box Cover,L	1
5	482396g	Box Cover,R Cover Cap,White	1
5	482393L	Box Cover,R Cover Cap,Blue	1
5	482392h	Box Cover,R Cover Cap,Red	1
5	482397c	Box Cover,R Cover Cap,Vista Camouflage	1
5	482397E	Box Cover,R Cover Cap,Reality Camouflage	1
5	482397F	Box Cover,R Cover Cap,Conceal Camouflage	1
5	482394L	Box Cover,R Cover Cap,Orange	1
5	482395E	Box Cover,R Cover Cap,Army Green	1
5	482394M	Box Cover,R Cover Cap,Quick Sand	1
5	482399A	Box Cover,R Cover Gray	1
6	482386g	Box Cover,L Cover Cap,White	1
6	482383L	Box Cover,L Cover Cap,Blue	1
6	482382h	Box Cover,L Cover Cap,Red	1
6	482387c	Box Cover,L Cover Cap,Vista Camouflage	1
6	482387E	Box Cover,L Cover Cap,Reality Camouflage	1
6	482387F	Box Cover,L Cover Cap,Conceal Camouflage	1
6	482384L	Box Cover,L Cover Cap,Orange	1
6	482385E	Box Cover,L Cover Cap,Army Green	1
6	482384M	Box Cover,L Cover Cap,Quick Sand	1
6	482389A	Box Cover,L Cover Cap,Gray	1
7	48316	Tapping Screw M5 x16	40
8	48270	Screw M6x20	8
9	70960	Spring Nut M6	6
10	48244	Rear Light Cover,R	1
11	48243	Rear Light Cover,L	1
12	48146	Box thermal baffle	1
13	48269	Hexagon Flange Bolt M6x16	2
14	48312	Box Rear Light Wire Nail	1
15	71960	Rear Reflector Red (For US)	2

**Body, Box, Tailgate**



Ref.No.	Part Number	Description	Q'ty
1	482476g	Box Rear Panel Cover Cap,White	1
1	482473L	Box Rear Panel Cover Cap,Blue	1
1	482472h	Box Rear Panel Cover Cap,Red	1
1	482477c	Box Rear Panel Cover Cap,Vista Camouflage	1
1	482477e	Box Rear Panel Cover Cap,Reality Camouflage	1
1	482477F	Box Rear Panel Cover Cap,Conceal Camouflage	1
1	482474L	Box Rear Panel Cover Cap,Orange	1
1	482475E	Box Rear Panel Cover Cap,Army Green	1
1	482474M	Box Rear Panel Cover Cap,Quick Sand	1
1	482479A	Box Rear Panel Cover Cap,Gray	1
1	483346g	Box Rear Panel Cover Cap,White (No LINHAI Logo)	1
1	483343L	Box Rear Panel Cover Cap,Blue (No LINHAI Logo)	1
1	483342h	Box Rear Panel Cover Cap,Red (No LINHAI Logo)	1
1	483347c	Box Rear Panel Cover Cap,Vista Camouflage (No LINHAI Logo)	1
1	483347e	Box Rear Panel Cover Cap,Reality Camouflage (No LINHAI Logo)	1
1	483537F	Box Rear Panel Cover Cap,Conceal Camouflage (No LINHAI Logo)	1
1	483534L	Box Rear Panel Cover Cap,Orange (No LINHAI Logo)	1
1	483345E	Box Rear Panel Cover Cap,Army Green (No LINHAI Logo)	1
1	483344M	Box Rear Panel Cover Cap,Quick Sand (No LINHAI Logo)	1
2	48137	Box Rear Panel Handle	1
3	11242	Tapping Screw ST4.2×13	4
4	48140	Box Rear Panel Lock Pin , L	1
5	48141	Box Rear Panel Lock Pin , R	1
6	48150	Handle Adjust Washer	2
7	48149	Handle Cotter Pin	2
8	48246	Box Rear Panel	1
9	48316	Tapping Screw M5 ×16	15
10	48138	Box Rear Panel Mounting Plate	1
11	11243	Tapping Screw ST4.8×10	2
12	10308	Spring Lock Washer 6	14
13	48148	Upper Retainer Cable	2
14	48147	Inner Hexagonal Flat Head Step Bolt M6×20	2
15	48144	Box Rear Panel Axis	1











**Front Suspension**



Ref.No.	Part Number	Description	Q'ty
1	48091	Carrier Bearing,Front,Lh	1
2	48094	Carrier Bearing,Front,Rh	1
3	48092	Bearing	2
4	11204	Circlip 55	2
5	70679	Nut M12x1.25	4
6	10792	Pin 3.2x22	4
7	48109	Arm Upper Frt Lh	1
8	48110	Arm Upper Frt Rh	1
9	48090	Ball Joint,Upper	2
10	11152	Circlip 32	2
11	48107	Scr Hxfl,Frt Arm	4
12	10795	Nut M10	8
13	48106	Bushing,Long	8
14	48105	Shaft Pivot	4
15	48108	Arm Lwr Frt Lh	1
16	48111	Arm Lwr Frt Rh	1
17	48089	Ball Joint,Lwr	2
18	70046	Circlip 34	2
19	84251	Cover, Arm Lwr Frt Lh	1
20	84252	Cover, Arm Lwr Frt Rh	1
21	11153	Screw M5X10	6
22	27074	Grease Fitting M6	4
23	48093	Front Shock Absorber Assy	2
24	11238	Bolt M10X1.25X57	4




# Rear Suspension



Ref.No.	Part Number	Description	Q'ty
1	48164	Carrier Bearing Wheel Rear Lh	1
2	48165	Carrier Bearing Wheel Rear Rh	1
3	27074	Grease Fitting M6	10
4	48077	Bearing	2
5	11155	Circlip 63	2
6	48161	Shaft Pivot ,Lwr	2
7	48162	Scr Hxfl,Rear Arm,Lwr	2
8	48160	Shaft Pivot ,Upper	2
9	11146	Bolt M10X1.25X90	6
10	10795	Nut M10	18
11	48070	Bushing,Short	16
12	48074	Arm Upper Rear Lh	1
13	48075	Arm Upper Rear Rh	1
14	48106	Bushing,Long	4
15	48068	Shaft,Rear Upper Arm	2
16	48071	Scr Hxfl, Rear Upper Arm	2
17	70287	Square Rubber Plug	4
18	48072	Arm Lwr Rear Lh	1
19	48076	Arm Lwr Rear Rh	1
20	48073	Plug	4
21	48069	Shaft,Rear Lwr Arm	4
22	84251	Cover, Arm Lwr Rear Lh	1
23	84252	Cover, Arm Lwr Rear Rh	1
24	11153	Screw M5X10	6



**Steering**



Ref.No.	Part Number	Description	Q'ty
1	10501	Pin 2.5×25	2
2	27067	Nut M10X1.25	2
3	48102	Steering Tie-Rod,Rh	1
4	48326	Tie	2
5	48098	Steering Motor	1
6	11161	Bolt M8X90	2
7	11244	Bolt M8×80	1
8	10783	Bolt M8X20	2
9	11145	Nut M8	6
10	48103	Steering Tie-Rod,Lh	1
11	48104	Steering Motor Sheet	2
12	26925	Steering Wheel	1
13	26932	Steering Wheel Holder	1
14	26934	Steering Cover	1
15	10305	Screw M5X10	6
16	48097	Steering Column Assy.	1
17	10032	Washer 12	1
18	10054	Washer Spring 12	1
19	26257	Nut M12	1
20	73143	Shoulder Bolt M10×1.25×30	2
21	73125	Bushing For Adjustable Steering Wheel	2
22	10795	Nut M10	2
23	48194	Shaft Steering	1
24	73118	Adjustment Cylinder, Old	1










**Fuel Tank, Steel**




Ref.No.	Part Number	Description	Q'ty
1	48120	Fuel Tank Comp Steel	1
2	48673	Cap Fuel Tank	1
3	73051	Rubber Damper	2
4	48121	Strap For Steel Fuel Tank Mounting	2
5	73052	Rubber Strap	2
6	11145	Nut M8	2
7	25037	Rollover Valve	1
8	880.021	Bracket, Rollover Valve	1
9	10183	Bolt M6X16	1
10	48032	Hose 1	1
11	48033	Hose 2	1
12	48124	Fuel Pump	1
13	73154	Sealing For Fuel Pump_Steel Tank	1
14	47606	Bracket For Fuel Pump	1
15	10087	Bolt M6X10	6
16	11019	Washer Spring 6	6
17	73145	Quick Fitting Assy 9.49	1
18	73146	Quick Fitting Assy 7.89	2
19	48029	Fuel Line 1	1
20	48122	Clip 14.6	5
21	48318	Fuel Filer	1
22	48415	Fuel Filer Support	1
23	48030	Fuel Line 2	1
24	71658	Clamp 8/14	1
25	48673	Cap Fuel Tank	1







**Gear Selector (NEW MODEL)**



Ref.No.	Part Number	Description	Q'ty
1	48442	Shift Mounting Plate Assembly	1
2	10783	Bolt M6×25	2
3	73705	Shift Board	1
4	48045	Knob Shifter	1
5	73706	Front Shift Rocker Arm	1
6	48053	Cover, Dust	1
7	48047	Spring, Shifting	1
8	48046	Pin, Gearshifter	1
9	11168	Washr 8	1
10	10685	Cotter Pin 2X16	1
11	11246	Spring Retainer 6	1
12	10140B	Bolt M6×12	1
13	48443	Cable, Shifter	1
14	48444	Rocker	1
15	10187	Bolt M6×25	1
16	10657	Nut M10	1
17	48350	Shift Guard Plate Support Plate	1
18	10106	Washer Spring 8	2
19	48445	Bracket	1
20	48558	Cover	1
21	11256	Core Pulling Rivets 3X10	3








Box Assy			
Ref.No.	Part Number	Description	Q'ty
1	48132	Box Floor Cover	1
2	48133	Cargo Handle Ass'Y	1
3	11101	Bolt M8X45	4
4	11145	Nut M8	4
5	48134	Rubber Sheath	8
6	48135	Pedal Spring ,L	1
7	48136	Pedal Spring ,R	1
8	48139	Lock Seat,Rear Trunk	2
9	10278	Bolt M6X22	4
10	10104	Nut M6	4
11	48142	Rear Side Protecting Plate,Lh	1
12	48143	Rear Side Protecting Plate,Rh	1
13	10783	Bolt M8X20	6
14	48316	Tapping Screw M5 x16	2
15	26786	Cap,Protector End	2
16	48313	Pin Shaft ,Rotation	2
17	10140B	Bolt M6X12	2
18	26784	Damper	1
19	10089	Washer 10	3
20	10021	Pin 2.5x20	2
21	73161	Pin Axle	1
22	48151	Damper, Cargo Box Adjusting	2
23	11176	Nut M6	2
24	48147	Bolt	2




## Removable iron cargo tank assembly (Add long)



Ref.No.	Part Number	Description	Q'ty
1	48559	Box Floor Cover (Add long)	1
2	48134	Rubber Sheath	8
3	48135	Pedal Spring ,L	1
4	48136	Pedal Spring ,R	1
5	48436	Cargo Handle Ass'y	1
6	26786	Cap,Protector End	2
7	11101	Hexagon Flange Bolt M8×45	4
8	11145	Nut M8	4
9	48313	Pin Shaft ,Rotation	2
10	10140B	Hexagon Flange Bolt M6×12	10
11	26784	Damper	2
12	10089	Washer 10	6
13	10501	Cotter Pin 2.5X25	4
14	73161	Pin Axle	2
15	48151	Damper, Cargo Box Adjusting	2
16	11289	Nut M6	2
17	48437	Front cover welded assembly	1
18	10183	Hexagon Flange Bolt M6×16	19
19	11233	Nut M6	5
20	10783	Hexagon Flange Bolt M8×20	2
21	10882	Nut M8	2
22	48560	The left side plate welded assembly (Add long)	1
23	48561	The right side plate welded assembly (Add long)	1
24	84401	Side rubber stopper	2


## Removable iron cargo tank assembly (Add long)



Ref.No.	Part Number	Description	Q'ty
25	55043	Hook	2
26	84400	Rail cargo box handle assembly	2
27	84403	Box cable (left)	1
28	84405	Box cable (right)	1
29	84414	The closure	6
30	55045	Rear cover assembly	1
31	55046	Handle(left)	1
32	55047	Handle(right)	1
33	55048	Rear cover rubber stopper	2
34	11105	Bolt M6X35	4
35	84409	Lasso plate (left)	1
36	84410	Lasso plate (right)	1
37	73058	Nylon Sheath	2
38	10032	Washer 12	6
39	10792	Cotter Pin 3.2X22	2
40	48440	Bracket,tailight	2
41	48441	Box thermal baffle	1
42	48171	Pin Axle	2
43	48562	I - Shaped Rubber Damper	2
44	48172	Pin, R	2
45	73492	Rubber Dampere	2




**Electrical**



Ref.No.	Part Number	Description	Q'ty
1	48299	Wiring Harness	1
2	48301	Cable Of Starting Motor	1
3	48302	Cable Of Battery Negative	1
4	48303	Cable Of Battery Positive	1
5	48304	Cable Of Frame	1
6	10183	Bolt M6×16	5
7	48316	Tapping Screw M5×16	5
8	26434	2WD/4WD Switch	1
9	70400	Accessory Socket Assy	1
10	71602	Starting Relay	1
11	11233	Nut M6	4
12	71603	Rectifier Regulator	1
13	10182	Bolt M6×30	4
14	35088	Reversing Buzzer	1
15	35083	Auxiliary Relay	6
16	48360	5 AMP Fuse	1
17	48361	10 AMP Fuse	1
18	48362	15 AMP Fuse	4
19	48363	20 AMP Fuse	1
20	84275	30 AMP Fuse	1
21	71474	EFI Relay	1
22	48293	Parking Switch	1
23	73436	High/Low Beam Switch	1
24	26272	Protector	2

**Electrical**




Ref.No.	Part Number	Description	Q'ty
25	48711	Wiring Harness For EFI	1
26	48305	Solenoid Valve Controller	1
27	36120	Accessory Socket Assy For USB	1
28	73306	Rear DIFF Switch	1
29	85100	ECU(TFT screens are not suitable)	1
29	85101	ECU(The speed limit of 40km/h,TFT screens are not suitable)	1
29	85104	ECU(TFT screens are not suitable)	1
29	85105	ECU	1
29	85106	ECU(The speed limit of 40km/h)	1
29	85107	ECU	1
30	70822D	Ignition Coil	1
31	11260	Bolt M6x40	1
32	70407a	Battery (12V 18Ah)	1
33	48327	Plate For Battery	1
34	11145	Nut M8	2
35	48067	Fastening Rod Of Battery	2
36	71604	Battery (12V 18Ah) For EPS	1
37	48311	Taillight Transition Line (For USA)	1
38	48294	Tie	14
39	48191	Buckle	9
40	50280	Starting Relay	1
42	48397	Ignition Switch Assembly	1
43	48551	Ignition Switch Decal	1





**Brake System**



Ref.No.	Part Number	Description	Q'ty
1	48181	Brake Rotor, Driver	4
2	48000	Bolt, Brake Rotor	16
3	48173	Brake Caliper, Left, Front	1
4	10106	Spring 8	8
5	10105	Bolt M8x25 (10.9)	4
6	48182	Clamp 1	3
7	10183	Bolt M6X16	12
8	11233	Nut M6	2
9	10110	Bolt M6x20	2
10	48183	Clamp 2	11
11	48180	Hose 1	1
12	48184	Hose 2	1
13	48174	Brake Caliper, Right, Front	1
14	48185	Hose 3	1
15	48175	Master Cylinder	1
16	10059	Bolt M8x25	2
17	48003	Push Rod	1
18	73090	Clevis	1
19	10094	Cotter Pin 2X20	1
20	73091	Clevis Pin	1
21	48179	Brake Reservoir, Cover	1
22	48178	Brake Reservoir	1
23	48190	Tube	1
24	48186	Hose 4	1
25	48187	Fitting, Tee	1















Ref.No.	Part Number	Description	Q'ty
1	10795	Nut M10	4
2	48081	Ball Pin, Lh	1
3	48078	Front Stabilizer Bar	1
4	11145	Nut M8	4
5	48080	Ball Pin, Rh	1
6	27091	Rubber Support Seat	2
7	27090	Retaining Cover	2
8	10783	Bolt M8×20	4
10	48416	Rear View Mirror, L	1
11	11495	Bolt M6×16	2
12	48545	Center Mirror Kit	1
13	48546	Bracket, Center Mirror Kit	1
14	48417	Rear View Mirror, R	1
15	48269	Bolt M6×16	3
16	11809	Core Pulling Rivets 3.2X11	7
17	48689	Tool Box,Floor	1
18	48690	Tool Box,The Side Panel	1
19	48270	Screw M6×20	4
20	48270	Screw M6×20	4
21	48260	Tool Box,The Side Panel	1
22	48290	Assist Grip Assy	1
23	11145	Nut M8	4
24	10783	Bolt M8×20	4
25	48082	Front Stabilizer Bar	1
26	48691	Tool Box, Assembly	1






### Control screen (Options)




REF. No.	PART No.	DESCRIPTION	Q'TY
1	48680	Control screen assembly	
2	48681	Control screen	1
3	11804	Screw M4X10	4
4	11805	Washer 4	4
5	48682	Camera	2
6	11806	Screw M3X10	4
7	11807	Nut M3	4
8	11808	Washer 3	4
9	85105	ECU	1
9	85106	ECU(The speed limit of 40km/h)	1
9	85107	ECU	1
10	48684	LCD Meter	1
11	48685	Wire, Control screen	1
12	48686	Bracket, Camera, FR	1
13	11655	Bolt M5X12	2
14	11791	Nut M5	2
15	48687	Bracket, Camera, REAR	1
16	10783	Bolt M8X20	2
17	10882	Nut M8	2

**Control Screen,10 Inch (Options)**




REF. No.	PART No.	DESCRIPTION	Q'TY
1	48724	Control Screen Assembly,10 Inch	
2	48725	Control Screen	1
3	11804	Screw M4X10	4
4	11805	Washer 4	4
5	48682	Camera	2
6	11806	Screw M3X10	4
7	11807	Nut M3	4
8	11808	Washer 3	4
9	85105	ECU	1
9	85106	ECU(The speed limit of 40km/h)	1
9	85107	ECU	1
10	48684	LCD Meter	1
11	48726	Wire, Control Screen	1
12	48686	Bracket, Camera, FR	1
13	11655	Bolt M5X12	2
14	11791	Nut M5	2
15	48687	Bracket, Camera, REAR	1
16	10783	Bolt M8X20	2
17	10882	Nut M8	2
18	48727	Cover,LCD Screen,10 Inch	1
19	48316	Tapping Screw M5 X16	6
20	48314	Spring Nut M5	4
21	48728	Instrument Panel	1

**SHIELD RUBBER UNDER STEERING WHEEL (Options)**




REF. No.	PART No.	DESCRIPTION	Q'TY
1	47788	SHIELD RUBBER UNDER STEERING WHEEL	1
2	11334	TIE	1

## Options



Ref.No.	Part Number	Description	Q'ty
1	48721	ECU (SE08)	1
2	48722	Wiring Harness For EFI	1
3	50280	Starting Relay	1

**TOOLS**




2

REF. No.	PART No.	DESCRIPTION	Q'TY
1		TOOLS	1
2	80472	Writable diagnostic instrument (XCM-PT300X)	1
2	80473	Common diagnostic instrument (XCM-PT300)	1
3	80574	diagnostic instrument	1




**Cylinder Head Cover**



Ref.No.	Part Number	Description	Q'ty
1	35143	Intake Rocker Arm Comp	1
2	35144	Intake Rocker Arm Valve	1
3	35146	Adjusting Nut Valve	4
4	35147	Adjusting Screw Valve	4
5	35148	Exhaust Rocker Arm Comp	1
6	35149	Exhaust Rocker Arm Valve	1
7	35150	Bolt M14×1.25×12	2
8	35215	Washer 14	2
9	35142	Intake Rocker Shaft	1
10	35145	Exhaust Rocker Shaft	1
11	35110	Cylinder Head Cover	1
12	10187	Bolt M6×25	4
13	35111	Gasket	2
14	35107	Valve Adjust Cover	2
15	10110	Bolt M6×20	5
16	10186	Bolt M6×35	2
17	35108	Washer 6	5
18	10530	Bolt M6×55	4
19	10182	Bolt M6×30	2
20	35113	O-Ring 18×2.4	1
21	35112	Seal Cover	1
22	10140	Bolt M6×12	1

**Cylinder Head**



Ref.No.	Part Number	Description	Q'ty
1	10067	Thrust Nut M8	1
2	35097	Stud M8×68	1
3	35106	Gasket,Cylinder Head	1
4	10004	Thrust Nut M6	2
5	35098	Stud M6×72	2
6	10278	Bolt M6×22	2
7	35103	Water Outlet Joint, Cylinder Head	1
8	35104	Pipe,Cylinder Head	1
9	35109	Clip 7.5	2
10	35095e	Water Temperature Sensor	1
11	35171	Thermostat	1
12	35105	Spark Plug DPR7EA-9(NGK)	1
13	35135	Intake Valve	2
14	35137	Seat Spring Valve	4
15	35140	Seal Valve Stem	4
16	35136	Spring Valve	4
17	35138	Retainer Spring Valve	4
18	35139	Cotter Valve	8
19	35100	Cylinder Bolt M10×1.25×190	2
20	35101	Cylinder Bolt M10×1.25×200	2
21	35102	Washer, Cylinder Bolt	4
22	50076	Dowel Pin 8×14	2
23	35141	EXHAUST VALVE	2
24	35099	Stud M8×42	2
25	10186	Bolt M6×35	2










**Left Crankcase**



Ref.No.	Part Number	Description	Q'ty
1	10186	Bolt M6×35	3
2	10827	Bolt M6×80	3
3	10005	Bolt M6×60	2
4	10177	Bolt M6×40	1
5	35221	Bolt M8×38	3
6	35223	Oil Filter	1
7	35213	Bolt, Oil Filter	1
8	10843	O-Ring 10X1.8	1
9	35094	Dowel Pin 10×14	3
10	35118	Dowel Pin 13×18	4
11	35337	Speed Sensor	1
12	35225	O-Ring 14×1.44	1
13	10189	Bolt M6×16	1
14	10844	O-Ring 18×3.55	1
15	35224	Oil Dip Rod	1
16	1309283	Washer 12	1
17	50105	Drain Bolt M12×1.5	1
18	10847	Bearing 6307	1
19	10846	Bearing 6303C3	2
20	10848	Bearing 63/22	1
21	10849	Bearing 6202	1
22	35216	Left Crankcase	1

















**Transmission I**



Ref.No.	Part Number	Description	Q'ty
1	35320	Main Shaft. Gearshift	1
2	35309	Bell Plug 12	1
3	35307	Washer 17.5×26×1	1
4	35318	Driven Gear, Low Range	1
5	35314	Sliding Bush, Gearshift	1
6	35311	Circlip 25	4
7	35310	Spline Washer	2
8	35316	Driven Gear, High Range	1
9	35317	Bushing, Driven High Range Gear	1
10	35315	Driven Shaft	1
11	35308	Driven Output Gear	1
12	35312	Washer 20.5×30×1.5	2
13	35313	Chain, Reverse Gear	1
14	35319	Sprocket, Reverse Gear	1
15	10858	Needle Bearing K20×26×12	1
16	24407	Circlip 20	1
17	35271	Output Driven Gear	1
18	35276	Drive Bevel Gear Shaft	1
19	35274	Bearing Seat, Drive Bevel Gear	1
20	35286	Bolt M8×28	4
21	10855	Bearing 6305C3	1
22	35287	Bearing Limit	2
23	10276	Screw M8×25	4
24	35277	Adjust Washer, Drive Bevel Gear	1
25	35272	Drive Bevel Gear	1




**Transmission III**



Ref.No.	Part Number	Description	Q'ty
1	35330	Left Shift Fork	1
2	35327	Spring 1, Shift Fork	1
3	35326	Spring Seat	2
4	10129	Circlip 12	3
5	35333	Guide Bar	1
6	35329	Right Shift Fork	1
7	35328	Spring 2, Shift Fork	1
8	10186	Bolt M6×35	1
9	35306	Washer 6.6×22×2	1
10	35305	Torsion Spring, Driven Sector Gear	1
11	35304	Washer 13.5×22×1	1
12	35301	Driven Sector Gear	1
13	35302	Shaft, Driven Sector Gear	1
14	35303	Washer, Driven Sector Gear	1
15	35325	Hole Bolt M14×1.5	1
16	35324	Washer 14×22×1	1
17	35332	Limit Spring	1
18	10842	Friction Ball 3/8	1
19	35331	Shift Cam	1
20	35323	Limit Washer	1
21	35322	Spring, Gear Contactor	1
22	10135	Screw M5×12	1
23	35321	Gear Contactor	1
24	10187	Bolt M6×25	3
25	10329	Bolt M6×32	1
26	35242	Oil Seal 15×25×5	1




**Oil Pump**



Ref.No.	Part Number	Description	Q'ty
1	35197	Relief Valve	1
2	35200	O-Ring 10×2.3	1
3	35198	Relief Valve Body	1
4	35199	Oil Plug, Relief Valve	1
5	35201	Spring Relief Valve	1
6	35202	Spring Washer	1
7	10838	Circlip 12	1
8	35203	Pressure Strip, Relief Valve	1
9	10140	Bolt M6×12	2
10	10840	Circlip 11	1
11	35191	Sprocket, Oil Pump	1
12	35196	Chain, Oil Pump	1
13	35206	Gasket, Oil Pump	1
14	35195	Oil Pump	1
15	35192	Shaft, Oil Pump	1
16	35187	Cover, Oil Pump	1
17	35189	Outer Rotor, Oil Pump	1
18	35190	Inner Rotor, Oil Pump	1
19	35193	Dowel Pin	2
20	35194	Straight Pin	1
21	35188	Oil Pump Housing	1
22	10857	Screw M5×20	1
23	35204	Oil Strainer	1
24	10210	Bolt M6×14	1
25	35205	O-Ring 14×2.5	1

**Water Pump**




Ref.No.	Part Number	Description	Q'ty
1	35179	Water Pump Assy	1
2	35173	Water Pump Cover	1
3	35176	Gasket	1
4	35172	Water Pump Housing	1
5	10140	Bolt M6×12	1
6	35108	Washer 6	1
7	10182	Bolt M6×30	2
8	35175	Water Pump Shaft	1
9	10839	Circlip 10	1
10	35177	Oil Seal 10×20×5	1
11	70020	Bearing 6000	1
12	35178	Water Seal	1
13	35180	Impeller	1
14	10349	Bolt M6×50	1
15	10160	Bolt M6×70	1
16	35174	O-Ring 34×2.5	1
17	35182	O-Ring 21×2.5	1
18	35181	Water Outlet Pipe	1
19	10831	Screw M6×10	1








**Air Cleaner (OLD)**




Ref.No.	Part Number	Description	Q'ty
1	35356e	Air Cleaner Assy	1
2	35747	Clip 52/76	1
3	35358e	Feed Hose	1
4	35364	Filter	1
5	35359	Clip 2	1
6	35362	Clip, Air Cleaner Cover	2
7	35366	Spring Clip	1
8	35365	Hose 2,Air Cleaner	1
9	35363	Case, Air Cleaner	1
10	35361	Element Comp Air Cleaner	1
11	35367	Screw	1
12	35360	Cover, Air Cleaner	1
13	26345	Air Cleaner Joint Hose	1
14	26346	Clip, Air Cleaner Joint Hose	2
15	48035	Intake Hose	1
16	48010	Intake Hose Cover	1
17	10183B	Bolt M6×16	2
18	26760	Plastic Screw	3

## Air Cleaner(new)



Ref.No.	Part Number	Description	Q'ty
1	73835	OIL CAP	1
2	73823	COVER, AIR CLEANER	1
3	73825	WIRE SPRING FASTENER	3
4	73824	ELEMENT COMP AIR CLEANER	1
5	11492	BOLT M8×20	2
6	11455	NUT M8	2
7	73842	AIR CLEANER MOUNTING CLAMP	1
8	73826	CASE, AIR CLEANER	1
9	35670	CLIP 80	3
10	73834	AIR CLEANER INLET CONNECTION PIPE	1
11	73829	AIR CLEANER INTAKE PIPE	1
12	48646	AIR CLEANER CONNECTING PIPE	1
13	35747	CLIP 52/76	1
14	48710	PIPE BREATHER1	1
15	73752	HOOP 2	2
16	48252	PLASTIC SCREW	3
17	10183B	BOLT M6×16	2
18	48647	INTAKE HOSE COVER	1


**Exhaust**



Ref.No.	Part Number	Description	Q'ty
1	48037	Gasket,Exhaust Pipe	1
2	10079	Nut M8	3
3	48036	Pipe,Exhaust	1
4	70826	Oxygen Sensor	1
5	35370	Jount	1
6	11184	Bolt M10×60	2
7	11035	Washer 10	2
8	47076	Spring	2
9	47077	Spacer 13×35	2
10	48038	Muffler	1
11	48040	Soft Rubber Connection	2
12	11185	Bolt M8×35	2
13	11261	Bolt M8×68	1
14	48042	Spacer 11.7×46	1
15	48043	Wire Washer	2
16	10154	Bolt M10×1.25×70	1
17	48041	Connection Block	1
18	10795	Nut M10	1
19	48039	Cover,Muffler	1
20	11090	Washer 6	4
21	11019	Washer 6	7
22	11345	Bolt M6×16	4
23	26364	Washer,Muffler	1
24	11320	BOLT M6×16	3
25	26458	Tail Pipe	1




**Radiator**




Ref.No.	Part Number	Description	Q'ty
1	10183B	Bolt M6×16	6
2	36052	Collar	2
3	36053	Radiator Side Grommet,Up	2
4	36054	Radiator Side Grommet,Down	2
5	48013	Radiator	1
6	22907a	Safety Valve	1
7	48020	Thermostat Switch Assy	1
8	35354	Blower Assy	1
9	10004	Nut M6	4
10	11203	Clip 28	8
11	48017	Hose,Feed	1
12	48016	Hose,Return	1
13	48015	Bracket	1
14	10177B	Bolt M6×40	1
15	48018	Feed Hose, Valve	1
16	48019	Return Hose, Cylinder	1
17	48014	Clip 8	1
18	48066	Pipe,Safety Valve	1
19	48325	Pipe,Tank Recovery	1
20	22924	Clip	2
21	70338	Cover,Tank Recovery	1
22	70339	Washer,Tank Recovery	1
23	83456	Tank Recovery	1
24	10140B	Bolt M6×12	1

**Front Axle**




Ref.No.	Part Number	Description	Q'ty
1	26318	Nut, Front Output Shaft	1
2	26324	Washer, Front Output Shaft Nut	1
3	35428	O-Ring	1
4	26330	Coupler, Front Axle	1
5	35423	Oil Seal 48×65×9	1
6	26317	Bearing Retainer	1
7	35424	Bearing 6007	2
8	48286	Bevel Gear -Driving	1
9	35429	Needle Bearing	1
10	35410	Oil Seal 24×38×8	2
11	24305	Fill Plug	1
12	50082	O-Ring 30.5×3	1
13	73020	Drain Bolt	1
14	73021	Washer 10	1
15	48285	Front Axle Box Cover	1
16	26323	Adjusting Shim(61×48)	as needed
17	48287	Bevel Gear -Driven	1
18	26334	Top Bracket,Differential Gear	1
19	26332	Bracket,Differential	1
20	26331	Bolt M10×1.25×20	6
21	10959	Bearing 61912	1
22	26322	Adjusting Shim(83×71)	as needed
23	26315	Drive Clutch	1
24	26316	Drive Clutch Cover	1
25	35412	Circlip 62	1

**Front Axle**




Ref.No.	Part Number	Description	Q'ty
27	35401	O-Ring 141×2.4	1
28	48284	Gear Case, Front Axle	1
29	10059	Bolt M8×25	6
30	11075	Screw M8×8	1
31	35493	Washer 8	1
32	21112	Vent Nozzle	1
33	25107	Clip	1
34	48288	Vent Pipe	1
35	35389	O-Ring 81.2×1.9	1
36	35388	Gear Motor	1
37	35391	Screw M8×20	4
38	10957	Pin Shaft	1
39	26314	Shift Fork	1
40	35434	Drive Gear	1
41	11076	Pin 5×25	1
42	26327	Wearing Ring	2
43	35437	Gear(Center), Differential	2
44	26325	Washer	1
45	26326	Shim	1
46	35440	Driven Gear	1
47	26333	Gear Shaft	1
48	48283	Front Axle	1

**Rear Axle**



Ref.No.	Part Number	Description	Q'ty
1	35285	Nut, Rear Output Shaft	1
2	35284	Washer, Rear Output Shaft Nut	1
3	48115	Coupler, Rear Axle	1
4	11022	Bolt M8×50	4
5	48119	Mount Bracket-Parking Braking	1
6	35471	Oil Seal 35×61×9	1
7	11012	Bearing 30205	1
8	27583	Bevel Gear Bearing Housing	1
9	26311	O-Ring 69×3	1
10	27581	Bearing Sleeve	1
11	35277	Adjusting Shim, Bevel Gear -Driving	as needed
12	11013	Bearing 30206	1
13	48116	Bevel Gear -Driving	1
14	48112	Diff Solenoid	1
15	73013	O-Ring 17×3	1
16	26302	Oil Seal 30×50×13.5	2
17	21112	Vent Nozzle	1
18	25107	Clip	2
19	48376	Vent Pipe	1
20	83179	Bolt M18×1.25	1
21	83180	Washer 18	1
22	48114	Gear Case, Rear Axle	1
23	73020	Drain Bolt	1
24	73021	Washer	1
25	73030	Clutch Gear	1


**Rear Axle**



Ref.No.	Part Number	Description	Q'ty
27	48117	Bevel Gear -Driven	1
28	27587	Diff Case	1
29	27588	Hexagon Flange Bolt M10×1.25×16	8
30	10056	Bearing 110	1
31	35493	O-Ring 151×3	1
32	21106	Adjusting Shim	as needed
33	27589	Rear Axle Box Cover	1
34	10059	Bolt M8×25	8
35	73036	Wearing Ring	2
36	73035	Planetary Gear	2
37	73032	Gear Shaft	1
38	11024	Pin 4×30	1
39	73034	Side Gear Thrust-Washer	2
40	73031	Diff Side Gear	2
41	73040	Shift Return Spring	2
42	73038	Shift Lever Spring	1
43	27592	Shift Lever	1
44	27591	Shift Bar	1
45	73041	Shift Yoke	1
46	27590	Shift Pin	1
47	48113	Rear Axle	1
48	48377	Breathing Air	1
49	48434	Gasket, Bevel Gear -Driven	as needed



screen (Options)



REF. No.	PART No.	DESCRIPTION	Q'TY
1	48680	Control screen assembly	
2	48681	Control screen	1
3	11804	Screw M4X10	4
4	11805	Washer 4	4
5	48682	Camera	2
6	11806	Screw M3X10	4
7	11807	Nut M3	4
8	11808	Washer 3	4
9	48683	ECU	1
10	48684	LCD Meter	1
11	48685	Wire, Control screen	1
12	48686	Bracket, Camera, FR	1
13	11655	Bolt M5X12	2
14	11791	Nut M5	2
15	48687	Bracket, Camera, REAR	1
16	10783	Bolt M8X20	2
17	10882	Nut M8	2