

PARTS LIST

KNOW YOUR TILLER




Fig. 1


1. Clutch Lever
2. Handle Knobs
3. Fuel Tank Cap
4. Lower Handle
5. Oil Dipstick
6. Wheels
7. Depth Regulator Lever
8. Tines
9. Outside Tine Shields
10. Air Filter
11. Muffler
12. Upper Handle

PARTS LIST

PARTS LIST

Carefully remove the tiller from its packaging and check that the following parts are included:

- | | | |
|----------------------------------|-----------------------|-----------------------------|
| A. Tiller 1pc | J. Nut M6 6pcs | S. Nut M8 2pcs |
| B. Left Tines Assembly 1pc | K. Flat WasherØ6 6pcs | T. Screw M8x20 2pcs |
| C. Left Outside Tine Shield 1pc | L. Bolt M6x25 2pcs | U. Gasket 4pcs |
| D. Lower Handle 1pc | M. Bolt M8x45 2pcs | V. Nut M10 2pcs |
| E. Upper Handle Assembly 1pc | N. Bolt M8x40 2pcs | W. Flat WasherØ10 4pcs |
| F. Right Tines Assembly 1pc | O. Handle Knob 4pcs | X. Bolt M10x50 2pcs |
| G. Right Outside Tine Shield 1pc | P. Saddle Bolt 4pcs | Y. Manual 1pc |
| H. Wheel Assembly 1pc | Q. Linch Pin 3pcs | Z. Bottle of Engine Oil 1pc |
| I. Depth Regulator Lever 1pc | R. Bolt M6x16 4pcs | |



⚠ WARNING !

If any parts are damaged or missing, do not operate this tiller until the missing parts are replaced. Failure to heed this warning could result in serious personal injury.

⚠ NOTICE

Always recycle the packaging in accordance with local recycling programs.