

## SAFETY PRECAUTIONS

### WARNING:

1. Protect the unit from rain and moisture. Water penetration increases the risk of electric shock.
2. Keep the unit clean, contamination may increase the risk of electric shock
3. Please check the unit, cable and plug before using. If defects are detected, do not use the unit, never open the unit. Instead, have it opened and repaired only by qualified personnel who will use original spare parts. Damaged unit, cables and plugs increase the risk of electric shock.
4. Plug the unit within the listed voltage range on the charger.
5. Ensure children do not play with the appliance.

## PRODUCT SPECIFICATIONS

Material	ABS	Accessories	1* Zapper 1* User Manual
Size	6.3 x 6.3 x 14.6 inches		

This product has a 1-year limited warranty. For further information please visit our website at [www.techkogroup.com](http://www.techkogroup.com)

**Copyright Reserved**


☎ 1-888-883-2456

✉ [support@techkogroup.com](mailto:support@techkogroup.com)

# Indoor Zapper USER MANUAL

**TECHKO®**

Model: OSZ-9101



### Instructions


1. This unit is designed for indoor use only
2. Suspend the unit ideally around 5 ft. high and keep out of reach of children.
3. To be safe, please do not use the metal bar to touch the grid.
4. Do not use the appliance in locations where flammable vapor or explosive dust is likely to exist.
5. The unit is not suitable for use in barns, stables or areas that are damp or moist.
6. To replace the UV Bulb.
  - a) Unplug the unit for at least 60 seconds.
  - b) Remove the catch tray and the bottom net then follow the steps as instructed in on the next page.
7. Regularly clean the grid by using the brush to last its longevity.
8. During cleaning or repairing, the unit should be disconnected from the main supply ( use the isolated tool to uncharge the electric grid ) and wiped down with a damp cloth, removing any build up of dirt.
9. In other cases please bring the product to the factory or agents to be handled.
10. Voltage:120V 60Hz

### How to Remove the UV Bulb


1. Be sure to unplug the unit for at least 60 seconds.
2. Remove the collection tray.
3. Unscrew two screws from the bottom net.



4. Pull out the tube socket from the bottom net.



5. Pull out the tube from the lamp holder.



### Product Specification

Dimension	H: 370 mm / 14.6" Diameter: 160 mm / 6.5"	Grid Voltage	2300VDC 2.5 mA
Weight	1.2 kg/ 2.65 lbs	Tube	FL-6BL 6W
Voltage	120V 60Hz	Ref.Range	25m <sup>2</sup> / 300 sqft