



Techko Kobot, Inc.


📍 11 Marconi Street, Suite A, Irvine, CA 92618, USA

☎ 1-888-883-2456

✉ [info@techkokobot.com](mailto:info@techkokobot.com)

# USER MANUAL

Tabletop  
Handheld Vacuum



## Getting Started


### Operation



1

#### Press to open the top cover

Press the top tab on the side of the unit to open the top cover.



2

#### Insert AA batteries

Insert 2x AA batteries (sold separately) according to diagrams on the unit.



3

#### Flip power switch on

Turn the unit on and begin vacuuming dust and debris.

### Cleaning & Maintenance



1

#### Press to open the bottom cover

Press the bottom tab on the side of the unit to open the bottom cover.



2

#### Empty dustbin after use

Empty the contents of the dustbin into a trash bin.



3

#### Remove the filter

Remove the filter to clean other areas within the dustbin.



4

#### Clean dustbin

Clean out small, leftover dust and debris using a brush.

## Warranty Information

### Limited One Year Warranty & Return Instructions



This warranty is only valid in the USA for one year. This warranty does not cover damage caused by accident, misuse, abuse, or failure to follow instructions contained in the user manual.

#### Return Instructions:

Please call TECHKO KOBOT customer service line prior to returning product to the retail store or seeking warranty replacement.

TECHKO KOBOT Customer Service: 1-888-883-2456