

QUICK INSTALLATION GUIDE

GUÍA DEL USUARIO

14460 / 14461

SMART ANTENNA

**Before returning this product
please call us for support**

Download the FREE
antenna setup App



www.oneforall.com/assistantapp



14460



WARRANTY / GUARANTEE INFORMATION

1 Year Limited Warranty against defects in material and workmanship. ca warranty, or you may request a hard copy by calling 855-569-6595, or via mail to: Universal Electronics Inc., 1000 N. Scottsdale Road, Suite H300, Scottsdale, Arizona 85254. Please include your full name, product information, and contact information.

LIMITED WARRANTY

Warranty: Universal Electronics Inc. warrants this product to be free from defects for a period of one year from the date of purchase. This warranty does not apply to damage caused by accident, abuse, misuse, misapplication, or handling, or failure to follow instructions or as a result of any unauthorized modification only to the original buyer and is and shall be in lieu of any and all other warranties and of all other obligations or liabilities on the part of Universal Electronics Inc. for, nor authorizes any other person purporting to act on its behalf to modify or assume for it any other warranty or liability concerning this product. Universal Electronics Inc. under all circumstances for any warranty issue shall be limited to the product. It is recommended that the customer check their equipment on a regular basis.

Remedies: Your exclusive remedy under this Limited Warranty is that Universal Electronics Inc. will repair or replace, without charge for parts and/or labor, the product found to be defective.

Service Procedure: To obtain warranty service, visit www.oneforall.com/warranty, your full name, contact information, product serial number, and description or image of your sales receipt showing date of purchase.

Disclaimer: THE FOREGOING LIMITED WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY OF UNIVERSAL ELECTRONICS INC. WITH RESPECT TO THE PRODUCTS. THERE ARE NO OTHER WARRANTIES OR IMPLIED WARRANTIES OR CONDITIONS OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR ANY WARRANTY OF TITLE. THE FOREGOING LIMITED WARRANTY DOES NOT COVER DAMAGE TO THE PRODUCT CAUSED BY ACCIDENT, ABUSE, MISUSE, OR MISAPPLICATION. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

RECEPTION QUALITY AND THE NUMBERS OF CHANNELS RECEIVED ARE DEPENDENT ON THE BROADCAST TOWER, BROADCAST POWER, LINE OF SIGHT, TERRAIN, METAL CONSTRUCTION FACTORS, AND OTHER FACTORS.


LEGAL NOTICES
FCC STATEMENT:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference with other radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with other radio communications. However, there is no guarantee that interference will not occur in a particular area. If interference should occur, you may wish to take the following steps: (1) Turn the equipment off and on; (2) Increase the separation between the equipment and receiver; (3) Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the condition that you do not cause harmful interference. (2) This device must accept any interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance with the user's authority to operate the equipment.

1

First connect the USB cable of the antenna to a free USB port on your TV or set-top box. Alternatively connect the USB cable of the antenna to a suitable USB power supply unit (not included) and plug the power supply unit into a socket.

Conecte el cable USB con una entrada USB libre del televisor o del decodificador. Alternativamente: Conecte el cable USB de la antena a una fuente de alimentación USB (no incluida) y conecte esta a un enchufe.



Power adapter
NOT included

TV

USB

x1




M4 x 0.7 x 15.5mm (x2)



4 x 20mm (x2)

OR



USB


TV | SET-TOP BOX

TV | SET-TOP BOX

2

Then connect the coaxial cable attached to the antenna at the back of the TV or set-top box.

Conecte el cable coaxial incluyendo la funda de protección ANTENNA IN en la parte trasera de la TV o Set-top box.



OR




If you are not sure in which direction your TV towers are, please check www.channelchecker.com and it will tell you in 3 simple steps.

In order to improve the reception performance, look for a different position of the antenna by moving closer to or in a window and facing the direction of the TV towers. A / B or C.

You can also rotate the antenna while lying flat or standing for fine-tuning in order to improve reception even more.

TURN THE ANTENNA SLIGHTLY FOR BETTER SIGNAL STRENGTH
OR RECEPTION QUALITY - www.oneforall.com/support/antennas

II



OR

IV **IMPORTANT! - FINISH**

Now you can perform a channel scan on your TV: the TV to **ANTENNA** first, then choose **CHANNEL** AUTO PROGRAM, AUTO TUNING, AUTO SCAN or CHANNEL menu of your TV).

If the number of channels or the quality is poor, adjust the antenna's position and repeat step I + II + III of your TV.

IV

