

Manual of sprayer part for TSC web use only
4428577

1. Unscrew the Trigger head from the tank.
2. Fill the liquid (only for water).
3. Replace Trigger head. Secure firmly.
4. Continue to press the trigger to start spraying, turn the nozzle to get mist and stream.
5. Clean the sprayer after each use. Store sprayer in clean, dry area.