




# OWNER'S MANUAL

## 4ft Firewood Rack with Cover

**Model No.:** WR004



Read these instructions carefully and retain them for future use.

Customer Service

 1-470-239-3656

 [service@werph.com](mailto:service@werph.com)

**[www.werph.com](http://www.werph.com)**

## GENERAL SAFEGUARDS

1. Please read the owner's manual carefully before assembling.
2. Place the firewood rack on a hard, dry surface.
3. Do not overload the log rack — holds up to 1/2 face-cord of firewood.
4. Firmly secure all the bolts, screws and knobs before use.
5. Do not allow children to play with or around the log rack.

## CAUTION:

Use CAUTION when erecting the frame. Use safety goggles during installation. Secure and bolt together overhead poles during assembly. Be aware of pole ends.

## CLEANING AND CARE

A tight cover ensures longer life and performance. Always maintain a tight cover. Loose fabric can accelerate deterioration of cover fabric. Immediately remove any accumulated snow or ice from the roof structure with a broom, mop or other soft-sided instrument. Use extreme caution when removing snow from cover- always remove from outside the structure. DO NOT use hard-edged tools or instruments like rakes or shovels to remove snow. This could result in punctures to the cover. DO NOT use bleach or harsh abrasive products to clean the fabric cover. Cover is easily cleaned with mild soap and water.

### CALIFORNIA PROPOSITION 65 WARNING

This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer.

For more information, go to <https://www.p65warnings.ca.gov/>.

## BEFORE ASSEMBLING

### Tools Required:







Wrench. For tightening all bolts and nuts.

It's included in hardware list.





### Notice:

1. Follow the installation instructions. Please confirm all accessories are present before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, contact our customer service.


| No. | Image                                                                                        | QTY |
|-----|----------------------------------------------------------------------------------------------|-----|
| 1   |             | 2   |
| 2   |            | 4   |
| 3   |           | 4   |
| 4   |           | 8   |
| 5   |           | 6   |
| 6   | Cover<br> | 1   |

### Hardware List


| No. | Image                                                                                 | QTY |
|-----|---------------------------------------------------------------------------------------|-----|
| A   |    | 8   |
| B   |    | 16  |
| C   |    | 24  |
| D   |    | 8   |
| E   |  | 2   |




1




2



3



4



Werph warrants to the original consumer-purchaser only that this product shall be free from defects in workmanship and materials after correct assembly and under normal and reasonable home use for the periods, normal residential use and recommended care for 1-Year Limited Warranty from the date of original retail purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Requests for expedited shipments of warranted parts will be at the consumer's / purchaser's expense. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown on the purchaser's receipt.

This warranty is valid for the original consumer / purchaser only and excludes industrial, commercial or business use of the product, product damage due to shipment or failure which results from alteration, product abuse or product misuse whether performed by a contractor, service company or consumer. We will not be responsible for labor charges and/or damage incurred in installation, repair or replacement, nor for incidental or consequential damage.



**service@werph.com**



**1-470-239-3656**



**Mon-Fri, 8:30 AM-5:30 PM, EST**

**Werph**

 **service@werph.com**

 **1-470-239-3656**

 **Mon-Fri, 8:30 AM-5:30 PM, EST**