




Distributed by:
TRACTOR SUPPLY COMPANY
5401 VIRGINIA WAY
BRENTWOOD, TN 37027
For customer support,
call: 1-888-376-9601
www.TractorSupply.com

TIPS BEFORE YOU START:

1. Ensure that all parts are present prior to assembly.
2. Check all packing material carefully before discarding as some parts may be encased in the packing material.
3. Ensure you have sufficient space and people to assemble product safely.
4. During assembly, do not over-tighten any fittings, as this may damage the product.


Approximate
assembly time: **20 Minutes**

People
for assembly: 


Required assembly space:
Floor area 3ft. x 3ft. (0.9m x 0.9m)



A 1pc



B 1pc



C 1pc




D 2pcs




E 1pc




F 1pc




G 1pc



H 1pc




I 1pc




J 4pcs




K 1pc



L 1pc



M 1pc



N 4pcs



O 4pcs



Φ6x15mm

P 4pcs



Φ6x30mm

Q 4pcs



Φ8x35mm

R 14pcs



Φ6mm

S 2pcs



Φ8mm

T 2pcs



Φ12mm

U 2pcs



Φ14mm

V 1pc



Φ14mm

V₁ 1pc



Φ20mm

W 1pc



Φ10mm

W₁ 1pc



Φ22mm

X 1pc



Φ4mm

