

WARNING

Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the cabinet, gaining full access to the cabinet and contents

Setting Personal Combination

1. Turn the number dials to the preset combination 0-0-0
Note: Move number dials downwards for a smoother motion
2. The reset button is located inside the cabinet combination lock, next to the lock mechanism
3. Move the reset button to position B as shown in Picture 1
4. Turn the number dials to desired personal combination
5. Move the reset button to position A as shown in Picture 2

Note: Remember the personal combination code, this is the only code that will open the cabinet

Testing Personal Combination

1. With cabinet door open turn number dials to random numbers
2. Twist the door knob, the knob will not move and will be locked in place
3. Turn number dials to personal combination, twist door knob, the knob will move and will be unlocked

Using the Cabinet

1. Turn number dials to personal combination
2. Twist and pull door knob to open the cabinet
3. Close and lock the cabinet
4. For security purposes turn number dials to random numbers

Changing Personal Combination



1. Open the cabinet by turning number dials to personal combination
2. Follow steps 2-5 in “Setting Personal Combination” and “Testing Personal Combination”

Care and Maintenance

DO NOT use chemicals or cleaning agents to clean the lock box, if necessary use a dry duster or micro fiber cloth to remove any dust or smudges, Keep liquid and moisture away from the lock box

DO NOT force open the lock box it may be damaged

DO NOT over stuff the contents of the lock box or you can damage the handle or the contents





1 YEAR LIMITED WARRANTY

SAFE/LOCK BOX

BARSKA warrants this new safe/lock box to be free of defects in material and/ or workmanship under normal use for a period of twelve (12) months from the date product is purchased. This limited warranty is delimited to repair or replacement only. This warranty does not cover damage caused by improper installation or maintenance. BARSKA disclaims all liability for incidental or consequential damages resulting from misuse, abuse, accident (such as dropping), fire, flood, service or repairs other than those performed by BARSKA, acts of nature, or arising out of any breach of this warranty. Altering the product under any circumstances will automatically void the warranty.

For service under this limited warranty, please have available the proof of purchase and the purchase date and location as well as a detailed description of the problem. This warranty is not transferable and only applies to the original purchaser with a proof of purchase from BARSKA or from an authorized dealer. This warranty applies only to products purchased within the United States, excluding Alaska, the Hawaiian Islands and all U.S. territories in the Caribbean and the Pacific.

BARSKA will examine and go through troubleshooting procedures, product repair or replacement of defective part(s) or units with new part(s) or provide a new unit, if necessary, during the warranty period. Reasonable shipping/handling charges may apply and are based on Barska sole discretion. Purchaser shall be required to prepay Shipping/handling charges with a check or money order to BARSKA at time product is returned. The Return Merchandise Authorization Number (RMA#) and shipping/handling charge MUST be obtained from BARSKA in advance of return. BARSKA shall not be liable for damages or loss occurring during shipping. Please visit via www.barska.com or call 909.445.8168 to obtain the RMA#, Shipping/handling amount, and for more information.

BARSKA reserves the right to modify or discontinue, without prior notice to the purchaser, any model or style of the product. BARSKA will determine, at its sole discretion, whether a product will be repaired or replaced. BARSKA reserves the right to discontinue or change any feature of its products at any time. If an exact replacement or product is not available, BARSKA reserves the right to provide a part or product that matches as closely as possible.

LIMITATION OF REMEDIES

BARSKA disclaims any warranties, express or implied, whether of merchantability or fitness for a particular use, except as expressly set forth herein. The sole obligation of BARSKA under this limited warranty shall be to repair or replace the covered product, in accordance with the terms set forth herein. BARSKA expressly disclaims any lost profits, general, special, indirect or consequential damages which may result from breach of any warranty, or arising out of the use or inability to use any BARSKA product. Any warranties which are implied and which cannot be disclaimed shall be limited in duration to a term of one year from the date of original retail purchase.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

BARSKA
855 Towne Center Drive, Pomona, CA 91767

BC767

Note: All information, feature, and specification displayed herein are based on the data available at the time of publishing, thus they are subject to change without notice. All product pictures displayed herein are for illustration purposes only. The actual product may vary due to different circumstances.