

Transportation & Storage Requirements

1. When storing the product, it must be placed in a cool, dry, dust-free place, away from direct sunlight and rain.
2. During product transportation, loading and unloading, it is strictly prohibited to throw, drop, toss, trample and other barbaric operations.

Warranty

Twelve (12) months for workmanship of the product, except for wearing parts. Warranty period starts from the product purchase date. Warranty covers material quality and workmanship only. Warranty does not cover product for issues caused by improper usage or any operation not in accordance with the specifications of this manual. Any modification or tampering with the product in any way voids the warranty.