

**2,200
LUMEN**


SURGE[®]

UTILITY LED WORKLIGHT

OWNER'S MANUAL

Model WKL6022AS

SAVE THIS MANUAL FOR FUTURE REFERENCE



IMPORTANT SAFETY WARNINGS

**READ ALL SAFETY WARNINGS AND INSTRUCTIONS CAREFULLY
BEFORE ASSEMBLING AND OPERATING YOUR WORKLIGHT.**

- Do not look directly at the lit lamps to avoid eye injuries.
- Always keep the worklight away from any flammable surface or materials.
- Always check for damage or worn-out parts before using the worklight. Broken parts will affect the worklight operation. Replace or repair damaged or worn parts immediately. If repairs are needed, consult a professional electrician.
- Battery contains lithium, which may explode if not used, handled, or discarded properly. Do not discard, soak in water, or use in environments exceeding 140° F (60° C).
- Do not use during charging, as this will affect the battery lifespan and may cause accidental explosions.
- Do not modify the worklight in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the product. Do not use the worklight for anything other than its intended purpose.
- Store the worklight in a secure place out of reach of children. Inspect the worklight for good working condition prior to storage and before each use.

USE CAUTION AND COMMON SENSE WHEN OPERATING YOUR WORKLIGHT.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

ASSEMBLY INSTRUCTIONS

WORKLIGHT PARTS

1. Light Head
2. Flashlight
3. Area Lights Power Switch
4. Flashlight Power Switch
5. Tripod Stand
6. Power Bank /Charing Port (in back)



ATTACHING WORKLIGHT TO TRIPOD STAND

1. Remove top protective cap from camera mount before using tripod.
2. Press triangle shape lock on bottom of tripod to release legs. Place the tripod stand ⑤ on a flat surface.
3. Attach light head ① to tripod stand ⑤ using camera mount on bottom of light.
4. Tripod stand can be extended to 60 inches. Rotate locking rings on each section of stand to extend section, then tighten locking ring to secure.

OPERATION

ADJUSTING THE WORKLIGHT DIRECTION

1. Lift each light panel, then rotate each panel up to 270° to point light in desired direction.
2. Light head has built-in magnets and hanging clip on base of light.

OPERATION

Left Switch (Flashlight): High / Low / Flashing.

Right Switch (Area Lights): White High / White Low / Amber High / Amber Low / White & Amber High / Long press, Red / Red Flashing.

MAINTENANCE

Clean the lens and stand regularly with a non-abrasive cleaner.

⚠ WARNING: Always make sure the worklight completely cool before attempting to clean.

1-YEAR LIMITED WARRANTY

For 1-year from date of purchase, Fair Game Group warrants the LED Worklight against defects due to workmanship or materials to the original purchaser. Fair Game Group's obligations under this warranty are limited to the following guidelines:

- This warranty does not cover units that have been altered/modified or damaged due to: normal wear, rust, abuse, improper maintenance and/or improper use.
- This warranty does not cover surface scratches or heat damage to the finish, which is considered normal wear.
- Fair Game Group may elect to repair or replace damaged units covered by the terms of this warranty.
- This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers.

Fair Game Group requires reasonable proof of purchase. Therefore, we strongly recommend that you retain your sales receipt or invoice. To obtain replacement parts for your LED Worklight under the terms of this warranty, please contact Customer Service Department at 855-735-9922 or help@fairgameus.com for a **Return Authorization Number** and further instructions. **A receipt or proof of purchase will be required.** Fair Game Group will not be responsible for any units forwarded to us without prior authorization.

EXCEPT AS ABOVE STATED, FAIR GAME GROUP MAKES NO OTHER EXPRESS WARRANTY.

THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO 1-YEAR FROM THE DATE OF PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

ANY LIABILITY FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE FAILURE OF THE LED WORKLIGHT TO COMPLY WITH THIS WARRANTY OR ANY IMPLIED WARRANTY IS EXCLUDED. CUSTOMER ACKNOWLEDGES THAT THE PURCHASE PRICE CHARGED IS BASED UPON THE LIMITATIONS CONTAINED IN THE WARRANTY SET OUT ABOVE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information
Unique Identifier: Model Number#: WKL6022AS
Responsible Party - U.S. Contact Information
Fair Game LLC
3204 Skylane Dr.
Carrollton, TX 75006
972-735-9922
FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Warning: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

OM6022AS
0126

©2026 Fair Game Group LLC.
Carrollton, Texas 75006 U.S.A.
www.surgeighting.com

Owner's Manual for Model
WKL6022AS