



Noah & Paw

FOLDABLE PET CRATE



SIZE:
M/L/XL/XXL

USER MANUAL

1 How to unfold the pet crate?

A



Open the zipper of the handbag and take it out.

B



Tear the Velcro which on the pet mat.

C



Unroll the pet mat.

D




Take out the pet crate.

E




Spread out the pet crate.

F



Pull up the side bracker straightly until you hear the clicking sound. (4sides)

G



Press down the side bracker straightly until you hear the clicking sound. (4sides)

H



Match corner poles to corners and secure with Velcro

I



The installation is complete


2 How to fold the pet crate for storage?

A



Tear off the Velcro and take out the pad.

B



Slide the switch toward the direction of the arrow, and press down the side bracket. (4sides)

C



Slide the switch toward the direction of the arrow and pull up the side bracket. (4sides)

D



Fold the crate in a diagonal

E



The crate is folded, as shown on the picture.

F



Put the crate on the pet pad.

G



Wrap up the crate with the pet pad, and seal with Velcro.

H




Put it into the storage bag

I



Storage completed.



Noah & Paw

noahandpaw.com

Support@noahandpaw.com

11030 SW 54th Street Davie Florida 33328