





Distributed by:
TRACTOR SUPPLY COMPANY
5401 VIRGINIA WAY
BRENTWOOD, TN 37027
For customer support,
call: 1-888-376-9601
www.TractorSupply.com


TIPS BEFORE YOU START:

1. Ensure that all parts are present prior to assembly.
2. Check all packing material carefully before discarding as some parts may be encased in the packing material.
3. Ensure you have sufficient space and people to assemble product safely.
4. During assembly, do not over-tighten any fittings, as this may damage the product.



Approximate
assembly time: **3 Minutes**

People
for assembly: 

Required assembly space:
Floor area 3ft. x 3ft. (0.9mx0.9m)



PARTS LIST

①	②	③	④	⑤	⑧	⑫
					 1 PC	
1 PC	1 PC	1 PC	1 PC	1 PC	⑨  1 PC	4 PCS
				⑥  1 PC	⑩  1 PC	
				⑦  1 PC	⑪  1 PC	

ASSEMBLY INSTRUCTIONS

