

W465134908 W465134909 WATER PUMP



MANUAL

CATALOGUE

1. SAFETY	1
2. BEFORE STARTING	2
3. START ENGINE	3
4. STOP ENGINE	4
5. MAINTENANCE	5
6. TROUBLE SHOOTING	9

SAFETY

BE CAREFUL!

NO USE IN HOUSE!

KEEP IN FLAMMABLE AWAY

NO!

MORE THAN 1M(3ft)

WHEN REFUELING:

STOP ENGINE!

NO SMOKING!

DO NOT SPILL!

TROUBLE SHOOTING

NOT PUMP UP

1 CHECK PRIMING WATER

2 CHECK STRAINER FOR CLOGGING

3 CHECK FOR AIR SUCTION

1 Check hose clamps

2 Check hose for damage

TROUBLE SHOOTING

ENGINE NOT START

2 CHECK SPARK

1 CHECK FUEL

START → NO → OK

2 Check spark → 1 Remove plug → OK

BEFORE STARTING

1.CONNECT HOSE

1. Insert
2. Tighten
3. Insert
4. Tighten

2.FILL PRIMING WATER

1. Remove plug
2. Fill water
3. Install plug

START ENGINE

- 1 ON
- 2 OPEN
- 3 CLOSE
- 4 ON
- 5 PULL
- 6 OPEN
- 7 FULL

MAINTENANCE

AIR CLEANER

WASH → DRY

NO GOOD CONDITION → KEROSENE → SOAK → SQUEEZE → ENGINE OIL

MAINTENANCE

REMOVE SPARK PLUG

SPARK PLUG

NO GOOD CONDITION → CLEAN → 0.7-0.8mm

STOP ENGINE

- 1 CLOSE
- 2 OFF
- 3 OFF

MAINTENANCE

CHECK OIL EVERY MORNING

MAINTENANCE

SAE10W-30 OR EQUIVALENT MOTOR OIL SAE 10W-30

CHANGE THE OIL AFTER THE FIRST MONTH OR AFTER 20 HOURS, WHICHEVER COMES FIRST. AFTER THAT, EVERY 6 MONTHS OR 100 HOURS, WHICHEVER COMES FIRST.

1 DRAIN 2 FILL 0.6L