

Do not plug the light string into an outlet until this item is fully assembled and the light strings are properly connected.
Please read the enclosed important safety instructions and cautions carefully prior to use.

Enclosed Parts

- * 2 Sets of Walls, Supporting Bar, Roof, Front Part of Coop, Ladder, Rooster, Hen, Chick, Large Scarf, Small Scarf
- * 6 Cotter Pins, 3 Wing Nuts, 7 Hex Screws, 1 Hex Wrench
- * 6 Lawn Stakes

Spare Parts


- * 2 Cotter Pins
- * 1 Wing Nut
- * 1 Hex Screw

Assembly Instructions


1. Carefully remove item from the protective wrap to avoid damaging any of the light bulbs or parts.

2. Combine the 2 sets of the walls by securing with hex screws through the aligned holes using the hex wrench, making sure the screws pass through the large holes first, then screw into the small holes.


3. Connect the light plugs L1 to L1 and secure with the pre-attached cap.



4. Attach the supporting bar between the 2 sets of walls by inserting the rods into the holes, then secure with cotter pins.




5. Fold the roof and secure with a hex screw through the aligned holes using the hex wrench, making sure the screw pass through the large hole first, then screws into the small hole.



6. Connect the light plugs L2 to L2 and secure with the pre-attached cap.


7. Attach the roof onto the walls by inserting the rods into the holes on both sides, then secure with wing nuts.




8. Connect the light plugs L3 to L3 and secure with the pre-attached cap.

9. Attached the rooster onto the roof by inserting the rods into the holes, then secure with a wing nut on the back rod.

10. Attach the ladder to the wall by inserting the rods into the holes, then secure with cotter pins.




11. Fold up the front part of the coop by inserting the rods into the holes, then secure with cotter pins.



12. Place the large scarf around the neck of the rooster.

13. Attach the front part of the coop to the wall by screwing the hex screws into the aligned holes using hex wrench, making sure the screws pass through the large hole first, then screw into the small holes.



14. Place the small scarf around the neck of the chick.

15. Connect the light plugs L4 to L4 and secure with the pre-attached cap.

16. Put the hen and the chick in the positions as shown.

17. Secure the item firmly into the ground using lawn stakes.



Trouble Shooting

If no lights light up:

1. Check the outlet to make sure the power is on.
2. Check the extension cord to make sure the power is on.