

Item: W81893

Size: 2" x 3"

No.: Hang Tag

BACK

FRONT

Size.: 1.75"(W) X 2"(H)

BATTERY OPERATION:

Requires 3 x 1.5V "AA" size or LR6 batteries (included).
This product includes batteries for demonstration purposes only. These temporary batteries should be replaced by an adult.

INSTRUCTIONS:

1. This is a light and sound activated item.
2. Slide ON/OFF switch on.
3. "ON" switch position, will activate the light and sound effects, along with the head rotating for a short period of time and then stop. Also, any loud sound will activate the owl again. When a person passes close to the owl skeleton it will be activated again by the light/movement sensor in the chest of owl in this switch position.
4. "OFF" switch position turns item off. "Try Me" function activated in the "OFF" position only.

BATTERY REPLACEMENT:

1. Open the battery compartment by loosening the screw until the lid can be removed.
2. Remove the demonstration batteries and insert new batteries.
3. Replace the lid and tighten the screw, ensuring the battery compartment is tightly secured.

IMPORTANT:

- Do not mix old and new batteries. Replace the whole set at one time.
 - Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
 - Remove the batteries during long periods of non-use.
- Battery leakage and corrosion can damage this product.

- Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are to be removed from the product before being charged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Batteries are to be inserted with the correct polarity.
 - Exhausted batteries are to be removed from the product.
 - The supply terminals are not to be short-circuited.
 - Dispose of batteries safely. Do not attempt to burn them. Use collection points where available.
 - Make sure battery compartments are secure.
 - Do not dispose of batteries in fire, batteries may explode or leak.
 - Clean the battery contacts and also those of the devices prior to battery installation.
- Packing has to be kept since it contains important information.

CAUTION: The batteries used with this product are small parts, they should be kept away from children. If you think batteries might have been swallowed, seek immediate medical attention.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.